


# Maytag DG22CT 02 - REAR VIEW



Maytag Residential Maytag DG22CT Dryer Parts Parts Diagram 02 - REAR VIEW

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	<a href="#">62739</a>		Nut, Lock
002	<a href="#">204439</a>			Screw And Fstner Assembly
003	NLA		Not Available	SCREW
004	<a href="#">210684</a>			Foot, Adjustable Leg
005	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
006	<a href="#">211881</a>			Grommet, Cord Part Not Used-Gas Models Only
007	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
008	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
009	<a href="#">301548</a>			Clamp, Ground Wire
010	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
011	NLA		Not Available	SCREW & WASHER ASSY.
012	NLA		Not Available	SPACER ASSY (WHT)
013	NLA		Not Available	FRONT PANEL (WHT)

014	Y305087	<a href="#">22003544</a>	Adjustable Leg W/Foot And Nut
015	NLA		Not Available (ALM)
"	Y305190	<a href="#">307104</a>	Top Cover Assembly
016	NLA		Not Available CONTROL SHROUD (WHT)
017	NLA		Not Available CABINET (WHT)
018	NLA		Not Available CABINET (WHT)
019	Y310632	<a href="#">1163839</a>	Screw
020	310933	<a href="#">33002194</a>	Nut, Speed
021	<a href="#">311155</a>		Ground Wire And Clamp
022	<a href="#">Y311270</a>		Washer, Terminal Block
023	Y311423	<a href="#">489483</a>	Screw 10-32 X 1/2
024	311484	<a href="#">112432</a>	Nut
025	<a href="#">Y312184</a>		Strap, Grounding
026	Y312209	<a href="#">W10001200</a>	Screw
027	Y312905		Not Available COVER, TERMINAL
028	Y312951		Not Available ACCESS COVER, BACK
029	<a href="#">313122</a>		Screw - Baffle To Tumbler
030	NLA		Not Available FILLER STRIP
031	<a href="#">Y313559</a>		Screw
032	<a href="#">Y313561</a>		Screw----NA
033	NLA		Not Available TOP COVER PLATE
034	NLA		Not Available SCREW
035	911050	<a href="#">4312464</a>	Screw

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>