


Maytag DG23CD 02 - REAR VIEW



Maytag Residential Maytag DG23CD Dryer Parts Parts Diagram 02 - REAR VIEW

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	210385			Lock Nut For Adjustable Leg
003	210684			Foot, Adjustable Leg
004	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
005	211881			Grommet, Cord Part Not Used-Gas Models Only
006	213007			Xfor Cabinet See Cabinet, Back
007	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
008	301548			Clamp, Ground Wire
009	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
010	Y302699	22003428		Leg, Adjustable
011	NLA		Not Available	SCREW & WASHER ASSY.
012	Y305087	22003544		Adjustable Leg W/Foot And Nut

013	Y305190	307104		Top Cover Assembly
014	NLA		Not Available	TOP COVER-ALMOND
015	NLA		Not Available	TOP COVER-HARVEST WHEAT
016	NLA		Not Available	CABINET-WHITE
017	NLA		Not Available	CABINET-ALMOND
018	NLA		Not Available	CABINET-HARVEST WHEAT
019	NLA		Not Available	COUPLING COLLAR-WHITE
021	NLA		Not Available	COUPLING COLLAR-ALMOND
022	NLA		Not Available	COUPLING COLLAR-HARV WHEAT
023	Y310632	1163839		Screw
024	310933	33002194		Nut, Speed
025	311155			Ground Wire And Clamp
026	Y311423	489483		Screw 10-32 X 1/2
027	311484	112432		Nut
028	Y312184			Strap, Grounding
029	Y312209	W10001200		Screw
031	Y312905		Not Available	COVER, TERMINAL
032	Y312951		Not Available	ACCESS COVER, BACK
033	313122			Screw - Baffle To Tumbler
034	Y313559			Screw
035	Y313561			Screw---NA
036	NLA		Not Available	TOP COVER PLATE
037	314663	214354		Screw, Top Cover To Cabnt.

the laundry company[®]

the laundry company[®]