


Maytag DG24CA 04 - FRONT PANEL\DOOR ASSY.



Maytag Residential Maytag DG24CA Dryer Parts Parts Diagram 04 - FRONT PANEL\DOOR ASSY.
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	204439			Screw And Fstner Assembly
002	212949	22001866		Screw, Relay
003	212982	22001650		Fastener, Spring
004	NLA		Not Available	ACCESS DOOR (WHITE)
005	NLA		Not Available	ACCESS DOOR-ALMOND
006	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
007	NLA		Not Available	KNOB AND SCREW
008	NLA		Not Available	FRONT PANEL-WHITE
009	NLA		Not Available	FRONT PANEL-ALMOND
010	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
011	Y304577	33001230		Hinge, Door
012	Y305753	W10169313		Switch-Dor
013	Y305754	W10169313		Switch-Dor
014	306436			Door Latch Kit--W
015	Y306668			DOOR (WHT)

016	NLA	Not Available	DOOR-ALMOND
017	NLA	Not Available	DOOR-HARVEST WHEAT
018	NLA	Not Available	INNER DOOR WITH KNOB
019	Y310376		Clip, Door Switch Harness
020	NLA	Not Available	BUSHING FOR ACCESS STUD
021	312369		Sleeve, Access Panel Stud Part Not Used
022	Y313340		LABEL, LINT SCREEN INSTRUCTION
023	Y313907		Fastener, Twin
024	Y313908		DOOR PANEL-WHITE
025	NLA	Not Available	DOOR PANEL-ALMOND
026	NLA	Not Available	DOOR PANEL-HARVEST WHEAT
027	Y313910		Clip, Door Liner To Outer Panel
028	Y313911		Door Strike Retainer
029	Y313927		INSTRUCTION LABEL
030	Y314062		Screw, Door Hinge And Panel
031	314077		Door Seal
032	NLA	Not Available	GAS IGNITION LABEL
033	314286		Seal For Front Panel
034	NLA	Not Available	SCREW FOR DOOR KNOB----NA

