

Maytag DG24CS 11 - 50 HZ CONVERSION LIST



[Maytag Residential Maytag DG24CS Dryer Parts](#) Parts Diagram 11 - 50 HZ CONVERSION LIST
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y014872			Screw, Coin Meter Stop -
002	211605			Bezel, Timer Dial
003	Y304656		Not Available	MOTOR (240V 50HZ)
004	Y304697			BURNER ASSEMBLY
005	Y304698		Not Available	GAS VALVE (240-50)
006	NLA		Not Available	PILOT SHIELD ASSEMBLY
007	NLA		Not Available	COMBUSTION CONE
008	305186			Pulley, Motor
009	NLA		Not Available	PILOT LAMP
010	Y305758			Timer 240-50
011	305812			Timer
012	306527	305812		Timer
013	NLA		Not Available	TIMER MOTOR 240-50
014	NLA		Not Available	MAIN WIRE HARNESS - DG
015	NLA		Not Available	MAIN WIRE HARNESS - DG
016	Y310693		Not Available	COMPRESSION SLEEVE

017	Y311711		Screw, Fuse Block
018	NLA	Not Available	AIR SHUTTER
019	Y312483		PILOT TUBE
020	Y313950		Element, Heater
021	NLA	Not Available	GAS CONTROL BRACKET
022	NLA	Not Available	GAS BURNER INSTRUCT LABEL

