


Maytag DG307 01 - BURNER ASSEMBLY



Maytag Residential Maytag DG307 Dryer Parts Parts Diagram 01 - BURNER ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y014872			Screw, Coin Meter Stop -
2	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	211642		Not Available	SCREW, No.6-20 X 3/8 INCH
4	300272			Pressure Regulator
5	301278			Pilot Shield
6	301286		Not Available	PILOT VALVE
7	Y301451		Not Available	HIGH LIMIT THERMOSTAT
8	301456		Not Available	CONVERSION KIT-NAT. TO LPG
9	301539			Conversion Kit
10	302523		Not Available	MIXING CHAMBER
11	Y302544		Not Available	BURNER ASSEMBLY
12	302680			Combustion Cone
13	302810			Screw Assembly - Blue Block Ope
14	303074		Not Available	PIPE AND BRACKET ASSEMBLY

15	303075	303919	Switch
16	310207		Screw, No.6 X 1/4 Inch
17	310484		Manifold, LPG 5 Inch
18	Y310632	1163839	Screw
19	Y310798		Burner Orifice Brass No.47
20	310803		Burner Orifice Black No.57
21	311065		90 Degree Elbow, 3/8 Inch
22	311162	Not Available	LABEL-NATURAL
23	Y311418		Pilot Orifice
24	Y311482		Pilot Orifice
25	311610		Pipe, 10-1/2 Inch
26	Y311639	63-3570	Burner Orifice
27	311640	Not Available	ORIFICE FOR MAIN BURNER
28	311910	Not Available	AIR SHUTTER
29	312208	Not Available	COVER FOR TERMINAL OPENING
30	312298		Support And Cover
31	312302		Insulation, Exhaust Duct Kit
32	Y312484		Pipe, 17-3/8 Inch
33	312676	Not Available	PIPE SUPPORT PLATE-SQ HOLE

