


# Maytag DG307 03 - CONTROL PANEL & COMPONENTS



Maytag Residential Maytag DG307 Dryer Parts Parts Diagram 03 - CONTROL PANEL & COMPONENTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205198		Not Available	BRACKET KIT - LEFT HAND
2	205199		Not Available	BRACKET KIT - RIGHT HAND
3	<a href="#">210745</a>			Wire Terminal
4	<a href="#">211252</a>			Screw, Ground Wire
5	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
6	<a href="#">211410</a>			Screw, HeX Head No.8 X 3/8 Inch
7	211737	<a href="#">248562</a>		Terminal
8	213077		Not Available	CAP FOR TIMER KNOB
9	213322		Not Available	MAYTAG DECAL
10	<a href="#">213323</a>			Fastener, Exhaust Duct Kit
11	302469		Not Available	HARNES FOR SHROUD
12	303088		Not Available	GAS VALVE WIRES WITH PLUG
14	303623		Not Available	MAIN WIRE HARNES
15	303625		Not Available	PUSH-TO-START TIMER

16	<a href="#">304126</a>		Control Panel, Sea-Mist
17	304127	Not Available	CONTROL PANEL KIT, SEA-MIST
18	<a href="#">Y304585</a>		Timer Motor RPR For 305214 Timer Only
19	<a href="#">Y310376</a>		Clip, Door Switch Harness
20	<a href="#">Y312140</a>		Wire Connector
21	<a href="#">312273</a>		Nut, Control Knob
22	<a href="#">312852</a>		Selector Knob-Clear Acrylic
23	312377	<a href="#">31-2377</a>	Minimanual
24	Y313160	Not Available	TIMER DIAL
25	410351	Not Available	HARNES RETAINER

