


Maytag DG308 02 - CONTROL PANEL & COMPONENTS



Maytag Residential Maytag DG308 Dryer Parts Parts Diagram 02 - CONTROL PANEL & COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205415	279347		Switch-Lid
2	211065			Spring, Index Wheel
3	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	211410			Screw, HeX Head No.8 X 3/8 Inch
5	212220	213501		Screw, No.6-20 X 1-1/8 Inch
6	213077		Not Available	CAP FOR TIMER KNOB
7	213117	67006908		Screw, Ice Rack
8	213322		Not Available	MAYTAG DECAL
9	213323			Fastener, Exhaust Duct Kit
10	214467		Not Available	NUT
11	214468		Not Available	BRACKET-LEFT HAND
12	214469		Not Available	BRACKET-RIGHT HAND
13	Y302454	33302454		Timer
14	303360		Not Available	TOP COVER-WHITE
15	303360A		Not Available	TOP COVER-DARK

15	303360A	Not Available	AVOCADO
16	303360B	Not Available	TOP COVER-DARK COPPERTONE
17	303360G	Not Available	TOP COVER-DARK GOLD
18	303360L	Not Available	TOP COVER-ALMOND
19	303360M	Not Available	TOP COVER-HARVEST WHEAT
20	303360N	Not Available	TOP COVER-FRESH AVOCADO
21	Y304106	Not Available	TIMER DIAL & KNOB, SUN-GLOW
22	304450	Not Available	MAIN WIRE HARNESS
23	304470	Not Available	TEMPERATURE SWITCH
24	304573	4314961	Swtch-Lite
25	Y304585		Timer Motor RPR For 305214 Timer Only
26	304647	Not Available	TIMER MOTOR
27	304670		Button Kit
28	312243	Not Available	CONTROL COVER-WHITE
29	312243B	Not Available	CONTROL COVER-DK COPPERTONE
30	312243G	Not Available	CONTROL COVER-DARK GOLD
31	312243L	Not Available	CONTROL COVER-ALMOND
32	312243M	Not Available	CONTROL COVER-HARVEST WHEAT
33	312243N	Not Available	CONTROL COVER-FRESH AVOCADO
34	312257	Not Available	BRACKET
35	312258		Actuator
36	312273		Nut, Control Knob
37	312303		Spring
38	Y313588	488234	Screw 8-32 X 1/4
39	313819	Not Available	BACK-UP PLATE
40	410351	Not Available	HARNESS RETAINER

