


# Maytag DG30CA 06 - SWITCH, TEMPERATURE & TERMINAL BLOCK

**MODEL DG30CA-CM-CMD-CT**  
**DOOR SWITCH, TEMPERATURE CONTROL & TERMINAL BLOCK**  
 DG30CMD-CT-ORIGINAL & SERIES 01  
 DG30CA-CM-ORIGINAL-SERIES 01 & SERIES 02



Maytag [Residential Maytag DG30CA Dryer Parts](#) Parts Diagram 06 - SWITCH, TEMPERATURE & TERMINAL BLOCK  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052749	<a href="#">62739</a>		Nut, Lock
002	NLA		Not Available	LOCK WASHER, 3/8 X 1/16
003	<a href="#">210866</a>			Nut, Twin Speed
004	NLA		Not Available	CAGE NUT
005	212220	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
006	<a href="#">212951</a>			Screw, No.6-32 X 1/4 Inch
007	NLA		Not Available	CLIP - ACTUATOR TO CABINET
008	<a href="#">Y330077</a>			Door Switch
009	Y330083		Not Available	CONTROL, TEMPERATURE
010	<a href="#">Y330087</a>			Drum Assembly Complete
011	<a href="#">Y330087</a>			Drum Assembly Complete
012	<a href="#">Y330092</a>			Terminal Block
013	NLA		Not Available	VAULT ASSEMBLY
014	NLA		Not Available	SCREW - BRACKET TO VAULT
015	331012	<a href="#">400022-1</a>		Screw

016	331014	<a href="#">8281196</a>		Screw
017	331026	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
018	NLA		Not Available	SQUARE WASHER FOR DRUM ROD
019	<a href="#">331058</a>			Grommet-Temp. Control Tubin
020	<a href="#">331061</a>			Knob For Temperature Contro
021	NLA		Not Available	MOUNTING PLATE-TEMP.CONTROL
022	NLA		Not Available	MOUNTING PLATE-DOOR SWITCH
023	NLA		Not Available	DRUM ROD
024	NLA		Not Available	SPACER - TEMP CONTROL COVER
025	NLA		Not Available	ACTUATOR FOR DOOR SWITCH
026	NLA		Not Available	SCREW-TEMP CONTROL LEVER
027	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
028	<a href="#">331151</a>			Lever-Temperature Control
029	NLA		Not Available	TWIN FASTENER WITH SCREWS

