


# Maytag DG30PC1 16 - OUTER TOP/BACK GUARD ASSEMBLY(DG50/30)



Maytag Residential Maytag DG30PC1 Dryer Parts Parts Diagram 16 - OUTER TOP/BACK GUARD ASSEMBLY(DG50/30)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN
001	A312511		Not Available	OUTER TOP ASSEMBLY
"	A312518	<a href="#">W10146831</a>		Ad-50 Oute
002	A150300	<a href="#">5307527001</a>		Switch
003	A121101		Not Available	JUNCTION BOX COVER ONLY
004	A121100			4 JUNCTIO
005	A801521	<a href="#">801521</a>		30-65 Back
006	A152014	<a href="#">152014</a>		1 4-20 Ser
007	A880500	<a href="#">W10148009</a>		6 Damper
"	A880501	<a href="#">W10148010</a>		8 Diameter Dam
008	A103500			LEVELING L