


Maytag DG30PN1 05 - FRONT PANEL ASSY. (LATCH TYPE-DG30/50)



Maytag Residential Maytag DG30PN1 Dryer Parts Parts Diagram 05 - FRONT PANEL ASSY. (LATCH TYPE-DG30/50)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A875300	W10147918		15-30- Ins
"	A875301	W10147919		25-50- Ins
002	A152215		Not Available	RIVET, POP (1/8")
003	A170330		Not Available	LATCH, DOOR (FRICTION)
004	A150300	5307527001		Switch
005	A150415		Not Available	SCREW, CRIMPTITE (PH. RD.HD.) (No.10-16 X 1/2" PH. RD. HD.)
006	A150301	150301		8-18 X 7
007	A313215	W10146843		DR SW Accu
008	A313217	W10146844		Main DR SW
"	A800445	W10147060		Micro DR S
"	A800446	800446		Micro DR S
009	A150025	150025		4-40 X 1
010	A153045	153045		4 Split L

011	A137004	137004	Ns Series
012	A153045	153045	4 Split L
013	A152016	152016	4-40 Hex N
014	A121405	121405	Rubber Gro
"	A404500	WB22X55	Switch
"	A404502	404502	White 0.6

