


# Maytag DG31CM 15 - CONTROL CENTER & COMPONENTS

## MODEL DG31CM CM CONTROL CENTER & COMPONENTS



Maytag [Residential Maytag DG31CM Dryer Parts](#) Parts Diagram 15 - CONTROL CENTER & COMPONENTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SCREW, No.5-40 X 3/8
002	<a href="#">210866</a>			Nut, Twin Speed
003	NLA		Not Available	CAGE NUT
004	212220	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
005	<a href="#">212951</a>			Screw, No.6-32 X 1/4 Inch
006	<a href="#">Y330064</a>			Pilot Light
007	<a href="#">Y330078</a>			Cool-Down Bypass Switch
008	Y330079		Not Available	SWITCH, PUSH-TO-START
009	<a href="#">330081</a>			Timer - CA 60 Minutes
010	Y330083		Not Available	CONTROL, TEMPERATURE
011	<a href="#">Y330092</a>			Terminal Block
012	NLA		Not Available	FRONT PANEL-WHITE
013	NLA		Not Available	FRONT PANEL-SHADED AVOCADO
014	NLA		Not Available	FRONT PANEL-ALMOND
015	NLA		Not Available	FRONT PANEL-HARVEST WHEAT

016	NLA		Not Available	FRONT PANEL-SUNSET CORAL
017	Y330100		Not Available	COIN BOX ASSEMBLY
018	NLA		Not Available	LOCK
019	NLA		Not Available	TIMER ACCUMULATOR - CM
020	NLA		Not Available	FRONT PANEL-WHITE
021	NLA		Not Available	FRONT PANEL-SHADED AVOCADO
022	330108L		Not Available	FRONT PANEL-ALMOND
023	330108M		Not Available	FRONT PANEL-HARVEST WHEAT
024	NLA		Not Available	FRONT PANEL-SUNSET CORAL
025	NLA		Not Available	MOUNTING PLATE (ACCUMULATOR)
026	Y330145		Not Available	CONTA ACCUMULATOR ASSEMBLY
027	NLA		Not Available	VAULT ASSEMBLY
028	330183		Not Available	TRANSFORMER
029	<a href="#">330184</a>			Timer Accumulator-25
030	<a href="#">Y330233</a>			Mounting Plt, Cm Timer Accum.
031	NLA		Not Available	SCREW - BRACKET TO VAULT
032	331014	<a href="#">8281196</a>		Screw
033	331026	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
034	331032	<a href="#">61002031</a>		Screw, Handle
035	<a href="#">331036</a>			Washer-Front Panel Screws
036	<a href="#">331041</a>			Button-Push-To-Start Switch
037	NLA		Not Available	PART NOT USED
038	<a href="#">331058</a>			Grommet-Temp. Control Tubin
039	<a href="#">331061</a>			Knob For Temperature Contro
040	NLA		Not Available	PART NOT USED
041	NLA		Not Available	MOUNTING PLATE-DOOR SWITCH
042	NLA		Not Available	SPACER - TEMP CONTROL COVER
043	331084		Not Available	SUPPORT ROD FOR UPPER DOOR
044	NLA		Not Available	HINGE RIVET
045	NLA		Not Available	SCREW-TEMP CONTROL LEVER
046	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
047	<a href="#">331151</a>			Lever-Temperature Control
048	NLA		Not Available	NUT FOR CONDUIT
049	NLA		Not Available	LIGHTING INSTRUCTIONS LABEL
050	NLA		Not Available	TWIN FASTENER WITH SCREWS