


MODEL DG-32 CT
CT CONTROL CENTER & COMPONENTS



Maytag Residential Maytag DG32CT Dryer Parts Parts Diagram 05 - CT CONTROL CENTER COMPONENTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	TICKET RECEIVER ASSEMBLY
002	212220	213501		Screw, No.6-20 X 1-1/8 Inch
003	212951			Screw, No.6-32 X 1/4 Inch
004	NLA		Not Available	FRONT PLATE, TICKET CONTROL
005	Y330064			Pilot Light
006	NLA		Not Available	CLIP, ACTUATOR (CABINET)
007	Y330083		Not Available	CONTROL, TEMPERATURE
008	NLA		Not Available	FRONT PANEL (WHT)
009	Y330100		Not Available	COIN BOX ASSEMBLY
010	NLA		Not Available	LOCK
011	NLA		Not Available	FRONT PANEL (WHT)
012	Y330147			Part Not Used
013	330183		Not Available	TRANSFORMER
014	Y330192		Not Available	SWITCH, PUSH TO START
015	NLA		Not Available	SCREW, BRACKET

016	331012	400022-1		Screw
017	331014	8281196		Screw
018	331026	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
019	331032	61002031		Screw, Handle
020	331036			Washer-Front Panel Screws
021	331041			Button-Push-To-Start Switch
022	331061			Knob For Temperature Contro
023	NLA		Not Available	MOUNTING PLATE-DOOR SWITCH
024	NLA		Not Available	SPACER - TEMP CONTROL COVER
025	NLA		Not Available	HINGE RIVET
026	NLA		Not Available	ELECTRICAL SHIELD
027	NLA		Not Available	MOUNTING PLATE-TICKET CONT
028	NLA		Not Available	RETAINER-TICKET CONTROL
029	NLA		Not Available	SCREW-TEMP CONTROL LEVER
030	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
031	331151			Lever-Temperature Control
032	NLA		Not Available	NUT, CONDUIT
033	210866			Nut, Twin Speed
034	NLA		Not Available	GROMMET, TEMP. CONTROL TUBIN
035	NLA		Not Available	TWIN FASTENER W/SCREWS

the laundry company[®]

the laundry company[®]