


Maytag DG34CQ 03 - ELECTRONIC CONTROL ASSEMBLY

MODEL DG34CD-CQ

CD-CQ ELECTRONIC CONTROL ASSEMBLY



Maytag [Residential Maytag DG34CQ Dryer Parts](#) Parts Diagram 03 - ELECTRONIC CONTROL ASSEMBLY
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|-------------------------|---------------|------------------------------|
| 001 | Y310632 | 1163839 | | Screw |
| 002 | Y330264 | | Not Available | WIRE HARNESS |
| 003 | Y330265 | | Not Available | WIRE HARNESS-DUAL CONTROL |
| 004 | Y330266 | | Not Available | MEMBRANE SWITCH |
| 005 | Y330268 | | Not Available | COIN ACCEPTOR ASSEMBLY \$.25 |
| 006 | NLA | | Not Available | COIN ACCEPTOR ASSEMBLY \$.10 |
| 007 | Y330270 | | Not Available | COIN SWITCH |
| 008 | 36001001 | | | Printed Circuit Board |
| " | 36001002 | | | Sensor |
| " | Y330273 | Y330316 | | Electronic |
| " | Y330315 | | | Switch Assembly |
| " | Y330319 | | Not Available | WIRE ASSEMBLY |
| " | Y330320 | | | Harness, Heat Sensor |
| 009 | 331233 | | | Plate For Electronic Contro |

| | | | |
|-----|------------------------|------------------------|------------------------------------|
| 010 | 331234 | | Spacer For Circuit Board |
| 011 | 331235 | 701719 | Nut, Hex |
| 012 | NLA | | Not Available BAIL FOR COIN RETURN |
| 013 | 331237 | | Screw |
| 014 | NLA | | Not Available LOCK WASHER |
| 015 | NLA | | Not Available BUMPER |
| 016 | NLA | | Not Available LABEL - \$.25 |
| 017 | NLA | | Not Available LABEL - \$.10-\$.25 |

