


Maytag DG382 01 - CONTROL PANEL

MODEL DE-DG382 CONTROL PANEL



Maytag Residential Maytag DG382 Dryer Parts Parts Diagram 01 - CONTROL PANEL

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	204807			Ground Wire, Supp. Plte To Top Cover
2	211168	W10139210		Screw, 8-18 X 5/16
3	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	214872			Palnut, End Cap Note: Nut, Lamp Holder
5	214894			Fastener, End Cap
6	214897			Pad, Control Panel
7	305205	694419		Mini-Buzzer
8	306479		Not Available	MAIN WIRE HARNESS
9	306483			Timer
10	306586		Not Available	MAIN WIRE HARNESS
11	306587		Not Available	MAIN WIRE HARNESS
12	306719		Not Available	CONTROL PANEL
13	312273			Nut, Control Knob
14	314184			Back Up Plate

15	314723	W10133501	Cap, Knob
16	314724		Knob For Timer
17	314725	33001500	Dial, Timer Indicator
18	314726		Not Available
19	314727	207927	END CAP - LEFT HAND
20	314728	210932	End Cap, Control Panel
21	910708	488234	Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
			Screw 8-32 X 1/4

