


Maytag DG406 04 - CONTROL PANEL & COMPONENTS



Maytag Residential Maytag DG406 Dryer Parts Parts Diagram 04 - CONTROL PANEL & COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	205198		Not Available	BRACKET KIT - LEFT HAND
2	205199		Not Available	BRACKET KIT - RIGHT HAND
3	205415	279347		Switch-Lid
4	210745			Wire Terminal
5	211065			Spring, Index Wheel
6	211252			Screw, Ground Wire
7	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
8	211410			Screw, HeX Head No.8 X 3/8 Inch
9	211605			Bezel, Timer Dial
10	211737	248562		Terminal
11	212220	213501		Screw, No.6-20 X 1-1/8 Inch
12	213077		Not Available	CAP FOR TIMER KNOB
13	213099			Lens For Control Panel
14	213323			Fastener, Exhaust Duct Kit
15	Y302454	33302454		Timer

16	302469	Not Available	HARNES FOR SHROUD
18	302806	Not Available	WIRE HARNESS
19	Y302829		Timer Dial And Knob
20	302934	Not Available	CONTROL PANEL WITH LENS
21	303088	Not Available	GAS VALVE WIRES WITH PLUG
22	Y304106	Not Available	TIMER DIAL & KNOB, SUN-GLOW
23	304125	Not Available	CONTROL PANEL, SUN-GLOW
24	304127	Not Available	CONTROL PANEL KIT, SEA-MIST
25	304128	WB2X9652	Insulation
26	Y304585		Timer Motor RPR For 305214 Timer Only
27	Y310376		Clip, Door Switch Harness
28	Y312140		Wire Connector
29	312257	Not Available	BRACKET
30	312258		Actuator
31	312261	Not Available	WASHER
32	Y312270		Clip, Spring Retainer
33	312303		Spring
34	313562	Not Available	BACK-UP PLATE
35	410351	Not Available	HARNES RETAINER

