


# Maytag DG407 06 - FRONT PANEL, DOOR & DRUM COVER



Maytag Residential Maytag DG407 Dryer Parts Parts Diagram 06 - FRONT PANEL, DOOR & DRUM COVER  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	212949	<a href="#">22001866</a>		Screw, Relay
2	300860		Not Available	SEAL, DRUM COVER
3	Y301451		Not Available	HIGH LIMIT THERMOSTAT
4	<a href="#">302452</a>			Door Liner
5	302453		Not Available	DOOR-WHITE
6	302453F		Not Available	DOOR-LIGHT GOLD
7	302453G		Not Available	DOOR-DARK GOLD
8	302453J		Not Available	DOOR-LIGHT AVOCADO
9	302453M		Not Available	DOOR-HARVEST WHEAT
10	302523		Not Available	MIXING CHAMBER
11	302526		Not Available	FRONT PANEL-WHITE
12	302526C		Not Available	FRONT PANEL-DARK COPPERTONE
13	302526H		Not Available	FRONT PANEL-SHADED GOLD
14	302526K		Not Available	FRONT PANEL-SHADED AVOCADO

15	302542	Not Available	PART NOT USED. (DG ONLY)
16	302542H	Not Available	ACCESS DOOR-SHADED GOLD
17	302542K	Not Available	ACCESS DOOR-SHADED AVOCADO
18	302542L	Not Available	PART NOT USED. (DG ONLY)
19	302542M	Not Available	ACCESS DOOR-HARVEST WHEAT
20	302542N	Not Available	ACCESS DOOR-FRESH AVOCADO
21	<a href="#">302680</a>		Combustion Cone
22	302771	Not Available	DRUM COVER WITH FELT
23	<a href="#">310207</a>		Screw, No.6 X 1/4 Inch
24	310217	Not Available	No Longer Available
25	<a href="#">311410</a>		Band
26	<a href="#">312238</a>		Door Seal
27	312301	Not Available	BUSHING FOR ACCESS STUD
28	312311	<a href="#">312311MAY</a>	Screw
29	<a href="#">312369</a>		Sleeve, Access Panel Stud Part Not Used
30	312622	<a href="#">22001496</a>	Front Panel Fastener And Screw
31	312680	<a href="#">31-2680</a>	Minimanual

