


Maytag DG408 08 - LINT SCREEN, TUMBLER (FRONT & BACK)



Maytag Residential Maytag DG408 Dryer Parts Parts Diagram 08 - LINT SCREEN, TUMBLER (FRONT & BACK)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y053241			Set Screw, Motor Pulley
2	Y055978			Rubber Adhesive, 2 Oz Tube
3	210720			Rivet, Bearing To Tumbler Fmt
4	Y303373	12001541		Drum Roller/Washer Assembly--W
5	Y303711			Sensor Ground Wire
6	Y303815	33001231		Front- Tumbler
7	Y304244			Motor Pulley With Set Screw
8	Y304388	33001003		Screen, Lint
9	Y304648	33001106		Back, Tumbler
10	Y304810		Not Available	OUTLET DUCT ASSEMBLY---S
11	Y305185	6-3051850		Pulley- MO
12	305187		Not Available	TUMBLER W/BAFFLES
13	306508			Tumbler Bearing Kit ---W
14	Y310376			Clip, Door Switch Harness
15	310557			Washer

16	Y310632	1163839	Screw
17	Y310759		Screw, Tumbler Baffles
18	310768	Not Available	WASHER
19	312535		Washer, Vault Mounting Brk.
20	312538	33001443	Nut, Hex
21	Y312907		Tumbler Baffle
22	Y312948	6-3129480	Shaft- Tumbler
23	Y312959		Poly "V" Belt For Tumbler
24	Y312961	W10116751	Screw
25	Y312964	Not Available	OUTLET DUCT - OUTER HALF
26	Y313347	312535	Washer, Vault Mounting Brk.
27	Y313541	33313541	Seal- Tumbler
28	Y313561		Screw---NA
29	313764	Not Available	SCREW
30	Y313796		Lint Seal
31	313915	31-3915	Tech Sheet
32	Y314110	33002917	Screw, No.10-16
33	Y314153	Not Available	TUMBLER No.
34	314154	Not Available	TUMBLER BAFFLE - SHORT
35	314155	33001004	Baffle, Tall
36	314158		Washer, Baffle To Tumbler
37	410233	9703438	Ring-Retrn
38	901220		Ground Wire
39	Y313795		Guide For Lint Screen

the laundry company[®]

the laundry company[®]