


Maytag DG409 08 - LINT SCREEN, TUMBLER (FRONT & BACK)



Maytag Residential Maytag DG409 Dryer Parts Parts Diagram 08 - LINT SCREEN, TUMBLER (FRONT & BACK)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y053241			Set Screw, Motor Pulley
2	Y055978			Rubber Adhesive, 2 Oz Tube
3	210720			Rivet, Bearing To Tumbler Fmt
4	Y303373	12001541		Drum Roller/Washer Assembly--W
5	Y303711			Sensor Ground Wire
6	Y251119	3177991		Screw
7	Y304244			Motor Pulley With Set Screw
8	Y304388	33001003		Screen, Lint
9	Y304648	33001106		Back, Tumbler
10	Y304810		Not Available	OUTLET DUCT ASSEMBLY---S
11	Y305185	6-3051850		Pulley- MO
12	305187		Not Available	TUMBLER W/BAFFLES
13	306508			Tumbler Bearing Kit ---W
14	Y310376			Clip, Door Switch Harness
15	310557			Washer

16	Y310632	1163839		Screw
17	Y310759			Screw, Tumbler Baffles
18	310768		Not Available	WASHER
19	312535			Washer, Vault Mounting Brk.
20	312538	33001443		Nut, Hex
21	Y312907			Tumbler Baffle
22	Y312948	6-3129480		Shaft- Tumbler
23	Y312959			Poly "V" Belt For Tumbler
24	Y312961	W10116751		Screw
25	Y312964		Not Available	OUTLET DUCT - OUTER HALF
26	Y313347	312535		Washer, Vault Mounting Brk.
27	Y313541	33313541		Seal- Tumbler
28	Y313561			Screw---NA
29	313764		Not Available	SCREW
30	Y313796			Lint Seal
31	313915	31-3915		Tech Sheet
32	Y314110	33002917		Screw, No.10-16
33	Y314153		Not Available	TUMBLER No.
34	314154		Not Available	TUMBLER BAFFLE - SHORT
35	314155	33001004		Baffle, Tall
36	314158			Washer, Baffle To Tumbler
37	410233	9703438		Ring-Retrn
38	901220			Ground Wire
39	300909	8009		Bulb-Light
40	300910		Not Available	RECEPTACLE
41	Y305146	306708		Tumbler Front Assembly
42	310207			Screw, No.6 X 1/4 Inch
43	Y312892	33312892		Lens
44	312903		Not Available	LAMP BRACKET
45	Y313795			Guide For Lint Screen

