


Maytag DG4910 02 - FRONT PANEL & DOOR ASSEMBLY

SECTION: FRONT PANEL & DOOR ASSEMBLY
 MODEL: DE-DG MODELS



Issue Date: 8/92

Maytag Residential Maytag DG4910 Dryer Parts Parts Diagram 02 - FRONT PANEL & DOOR ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	314942			INSTRUCTION LABEL
2	314941		Not Available	LABEL, INSTRUCTION
3	Y314062			Screw, Door Hinge And Panel
"	307099	33001230		Hinge, Door
4	314946			Handle White
5	Y307111		Not Available	DOOR ASSY. COMPLETE (WHT)
6	314966			Panel, Outer
7	306436			Door Latch Kit--W
8	212982	22001650		Fastener, Spring
9	Y310376			Clip, Door Switch Harness
10	Y305753	W10169313		Switch-Dor
11	314937			Seal, Front Panel
12	Y313907			Fastener, Twin
13	Y307998			Front Panel
14	312301		Not Available	BUSHING FOR ACCESS STUD

"	212949	22001866	Screw, Relay
15	312369		Sleeve, Access Panel Stud Part Not Used
16	302542	Not Available	PART NOT USED. (DG ONLY)
17	314936	33001305	Strike, Door
"	314944	33001305	Strike, Door
18	314935	33001192	Seal, Door
19	307098	Not Available	DOOR, INNER (W/SEAL)
20	Y313910		Clip, Door Liner To Outer Panel

