


Maytag DG701 05 - FRONT VIEW



Maytag Residential Maytag DG701 Dryer Parts Parts Diagram 05 - FRONT VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y300538		Not Available	FLUORESCENT LAMP
2	300541		Not Available	COVER FOR CONTROL PANEL
3	300552		Not Available	LAMP SOCKET
4	300838			Lint Screen
5	301010			Chime
6	301023			Lint Screen Retainer
7	301029		Not Available	DOOR HANDLE
8	301162		Not Available	SPRINKLER
9	301285		Not Available	GAS VALVE - NATURAL
10	301290		Not Available	ACCESS DOOR
11	301312		Not Available	FRONT PANEL
12	Y301336			Door Switch
13	301369		Not Available	SHAFT WITH SPIDER
14	301404	12001114		Kit- LP GA
15	301443		Not Available	OUTER DOOR PANEL
16	301446		Not Available	INNER DOOR PANEL

17	301448		Not Available	DOOR COMPLETE
18	301462		Not Available	TIMER
19	301464		Not Available	BAFFLE FOR DRUM
20	301465		Not Available	ELECTRONIC CONTROL
21	301486		Not Available	WIRE HARNESS-DOOR SWITCH
22	301744		Not Available	HINGE FOR DOOR
23	301746	Y304298		Hinge - Lower
24	Y302278			Motor
25	302954		Not Available	DRUM W/FELT - PORCELAIN
26	310074	8316805		Light-Ind
27	310089		Not Available	TENSION SPRING
28	310207			Screw, No.6 X 1/4 Inch
29	310217		Not Available	No Longer Available
30	310219			No.10z Fastener
31	310578		Not Available	WASHER
32	310579		Not Available	SCREW, No.10-24 X 11/16 INCH
33	Y310632	1163839		Screw
34	310744		Not Available	SCREW-LAMP RECEPTACLE TO BRACK
35	310768		Not Available	WASHER
36	310841		Not Available	PLUG BUTTON
37	310844	W10068250		Screw
38	Y302699	22003428		Leg, Adjustable
39	311033		Not Available	RUBBER SLEEVE
40	311036			Nylon Stud
41	311041		Not Available	PANEL-RIGHT WITH KNOCKOUT SECT
42	311042		Not Available	PANEL-LEFT SIDE
43	311147		Not Available	EXHAUST DEFLECTOR
44	311266		Not Available	SPRING
45	311276		Not Available	AIR FILTER
46	311277		Not Available	FILTER SPRING
47	311303		Not Available	RUBBER CAP
48	311339		Not Available	SET SCREW
49	311353		Not Available	BAG, LINT (DACRON)
50	302448	WB2X9430		Insulation
51	311501		Not Available	BACK PANEL
52	311503		Not Available	CONTROL PANEL
53	311504		Not Available	GLASS PANEL-LEFT HAND, GOLD
54	Y311505		Not Available	GLASS PANEL-RIGHT HAND, GOL
55	311512		Not Available	FASTENER
56	311535		Not Available	TIMER DIAL
57	311551			Clip For Door Harness
58	311614		Not Available	SCREW FOR DOOR RECESS
59	311657		Not Available	TRIM STRIP FOR FRONT PANEL
60	Y311916	22003781		Screw, Ground Strap
61	Y312060		Not Available	SHIELD FOR SPIDER---C
62	312208		Not Available	COVER FOR TERMINAL OPENING
63	200860		Not Available	RECEPTACLE FOR LAMP-RIGHT

64	200862		Not Available	BALLAST
65	201580		Not Available	SWITCH FOR FLUORESCENT LAMP
66	202807		Not Available	RECEPT FOR FLUORESCENT LAMP
67	210310	31001575		Bulb, Cylinder Light
68	210385			Lock Nut For Adjustable Leg
69	210590		Not Available	SPEED NUT
70	210609			Nylon Washer
71	210684			Foot, Adjustable Leg
72	210865		Not Available	FASTENER
73	211065			Spring, Index Wheel
74	211238		Not Available	PANEL BRACKET, LEFT
75	211239		Not Available	PANEL BRACKET, RIGHT
76	211244		Not Available	GASKET
77	211245		Not Available	SPRING CLIP-CONTROL COVER-REAR
78	211246		Not Available	SPRING CLIP
79	211247		Not Available	RETAINER
80	211250			Fastener
81	211252			Screw, Ground Wire
82	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
83	211512		Not Available	WASHER
84	211739			Screw, Cabinet To Base
85	211836		Not Available	CONTROL KNOB - T
86	212014		Not Available	MEDALLION
87	213077		Not Available	CAP FOR TIMER KNOB
88	052727		Not Available	HEX. NUT, 1/4-28
89	052792			Screw, 1 1/4-20 X 5/16
90	054151			Screw, No.4-40 X 1/4
91	Y059128			Standard 4" Vent Kit
92	Y059129	4396007RW		Vent Hood
93	Y059130			Pipe, Venting
94	Y059131			Elbow, Venting
95	059133		Not Available	ALUMINUM WINDOW 4X12X18
96	Y059134			PLATE, ALUM. WINDOW (15"X20")
97	Y059135			Vent Duct Assembly
98	059136		Not Available	EXTENSION FOR VENT DUCT

the laundry company®