

Maytag DG7600 04 - FRONT VIEW

SECTION: FRONT VIEW
MODEL: DE-DG MODELS



Issue Date: 6/90

56

Maytag Residential Maytag DG7600 Dryer Parts Parts Diagram 04 - FRONT VIEW
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	307104			Top Cover Assembly
"	204445			Screw And Fastener Assembly
2	Y305193			Console
"	Y313559			Screw
3	307124			Cabinet
"	Y310632	1163839		Screw
4	Y052740	62739		Nut, Lock
5	Y305086			Adjustable Leg And Nut
6	Y314137			Foot, Rubber
7	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
8	302542		Not Available	PART NOT USED. (DG ONLY)
9	Y307998			Front Panel
10	307099	33001230		Hinge, Door
11	Y307111		Not Available	DOOR ASSY. COMPLETE (WHT)
12	314966			Panel, Outer

