


Maytag DG7600 10 - REAR VIEW

SECTION: REAR VIEW
MODEL: DE-DG MODELS



Issue Date: 6/90

38

Maytag [Residential Maytag DG7600 Dryer Parts](#) Parts Diagram 10 - REAR VIEW
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y312905		Not Available	COVER, TERMINAL
7	Y305193			Console
8	215075			Fastener, Control Panel To Console
9	Y201808			Converter
10	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
12	211881			Grommet, Cord Part Not Used-Gas Models Only
13	307104			Top Cover Assembly
14	Y307998			Front Panel
15	Y313561			Screw----NA
"	Y310632	1163839		Screw
"	307124			Cabinet
16	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
17	Y052740	62739		Nut, Lock
18	Y314137			Foot, Rubber

19	Y305086		Adjustable Leg And Nut
20	Y312951	Not Available	ACCESS COVER, BACK
"	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	Y313559		Screw
21	311155		Ground Wire And Clamp
22	313122		Screw - Baffle To Tumbler
"	301548		Clamp, Ground Wire
23	214519		LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY

