


Maytag DG806 03 - CABINET REMOVED



Maytag Residential Maytag DG806 Dryer Parts Parts Diagram 03 - CABINET REMOVED
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|-------------|---------------|------------------------------|
| 1 | 014875 | | Not Available | CAP SCREW, No.14 X 1/2 |
| 2 | 015628 | | Not Available | BOLT, 5/16 X 3/4 HEX |
| 3 | 015700 | | Not Available | CAP SCREW, 1/4-20 X 1/2 |
| 4 | Y015825 | | | Clip, Motor To Motor Support |
| 5 | 051394 | | Not Available | BOLT, 5/16 X 2-1/8 |
| 6 | 052792 | | | Screw, 1 1/4-20 X 5/16 |
| 7 | Y053241 | | | Set Screw, Motor Pulley |
| 8 | 054865 | | Not Available | LOCK WASHER, 5/16 X 3/32 |
| 9 | Y059131 | | | Elbow, Venting |
| 10 | 210385 | | | Lock Nut For Adjustable Leg |
| 11 | 210684 | | | Foot, Adjustable Leg |
| 12 | 211642 | | Not Available | SCREW, No.6-20 X 3/8 INCH |
| 13 | 300831 | | Not Available | SHAFT AND SLIDE |
| 14 | 300839 | | Not Available | SEAL |
| 15 | 300840 | | Not Available | REDUCTION PULLEY |
| 16 | Y300844 | | | Exhaust Housing |

| | | | | |
|----|-------------------------|--------------------------|---------------|---|
| 17 | 300909 | 8009 | | Bulb-Light |
| 18 | 300910 | | Not Available | RECEPTACLE |
| 19 | Y301120 | | | Drum Pulley |
| 20 | 301122 | Y304596 | | Terminal Insulator Assembly |
| 21 | 301123 | | Not Available | MOTOR PULLEY |
| 22 | 301369 | | Not Available | SHAFT WITH SPIDER |
| 23 | Y302278 | | | Motor |
| 24 | 302535 | | Not Available | SUPPORT |
| 25 | 302536 | | Not Available | BASE |
| 26 | Y302699 | 22003428 | | Leg, Adjustable |
| 27 | Y302815 | | | Blower Housing With Bearing |
| 28 | 302943 | | | COVER WITH LINT SEAL-BLOWER |
| 29 | 302954 | | Not Available | DRUM W/FELT - PORCELAIN |
| 30 | 303709 | | | Clip And Insulator Assembly |
| 32 | 303846 | 22003781 | | Screw, Ground Strap |
| 33 | Y310376 | | | Clip, Door Switch Harness |
| 34 | 310578 | | Not Available | WASHER |
| 35 | Y310759 | | | Screw, Tumbler Baffles |
| 36 | 310768 | | Not Available | WASHER |
| 37 | 310933 | 33002194 | | Nut, Speed |
| 38 | Y311012 | | | Drive Belt |
| 39 | Y311013 | | | Motor Belt |
| 40 | 311019 | Y311946 | | Heater Wire 240 Volt |
| 41 | 311093 | | | Washer, Terminal Connection |
| 42 | 311265 | | | Spring |
| 43 | 311324 | | | Motor Base |
| 44 | 311534 | | | Felt Seal |
| 45 | Y311538 | | | Carbon Brush Holder |
| 46 | Y312057 | 910624 | | Screw |
| 47 | 312479 | | Not Available | LAMP SUPPORT FOR 3-2815 |
| 48 | Y313404 | Y301120 | | Drum Pulley |
| 49 | 211642 | | Not Available | SCREW, No.6-20 X 3/8 INCH |
| 50 | 251117 | | Not Available | LOCK WASHER |
| 51 | 301467 | | Not Available | SLIP RING |
| 52 | 301542 | | Not Available | WIRE HARNESS FOR DRUM |
| 53 | Y303877 | | Not Available | SWITCH, MOTOR EXTERNAL START No.303358-2, No.303358-4, 303358-7 |
| 54 | Y303879 | | | Switch, Motor External Start |
| 55 | 306208 | Y302278 | | Motor |
| 56 | 310204 | | Not Available | SNAP RING |
| 57 | 310262 | | | Washer |
| 58 | 310579 | | Not Available | SCREW, No.10-24 X 11/16 INCH |
| 59 | 311048 | | Not Available | WASHER, ALUMINUM |
| 60 | 311056 | | | Lamp Support |
| 61 | 311484 | 112432 | | Nut |
| 62 | Y311539 | | | Spring For Carbon Brush |
| 63 | 311540 | | Not Available | COVER FOR CARBON BRUSH |
| 64 | Y311542 | | Not Available | CARBON BRUSH |
| 65 | 311546 | 911445 | | Wire Connector |
| 66 | 810148 | | Not Available | SCREW |
| 67 | 301285 | | Not Available | GAS VALVE - NATURAL |

