


Maytag DG808 01 - CONTROL PANEL & COMPONENTS



Maytag [Residential Maytag DG808 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL & COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	200862		Not Available	BALLAST
2	201110		Not Available	WIRE CONNECTOR
3	201838			Starter Socket
4	201840	92790		Starter
5	202807		Not Available	RECEPT FOR FLUORESCENT LAMP
6	210587	W10116760		Screw
7	211065			Spring, Index Wheel
8	211168	W10139210		Screw, 8-18 X 5/16
9	211250			Fastener
10	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
11	211410			Screw, HeX Head No.8 X 3/8 Inch
12	212220	213501		Screw, No.6-20 X 1-1/8 Inch
13	213023		Not Available	RETAINER
14	213026		Not Available	CLIP

15	213077		Not Available	CAP FOR TIMER KNOB
16	213117	67006908		Screw, Ice Rack
17	213322		Not Available	MAYTAG DECAL
18	213323			Fastener, Exhaust Duct Kit
19	214468		Not Available	BRACKET-LEFT HAND
20	Y300538		Not Available	FLUORESCENT LAMP
21	301962		Not Available	SOCKET FOR LAMP
22	302524		Not Available	BRACKET
23	Y302543		Not Available	SPRING ASSEMBLY
24	302553		Not Available	SHAFT
25	Y303350		Not Available	SOLENOID
26	303360		Not Available	TOP COVER-WHITE
27	303360A		Not Available	TOP COVER-DARK AVOCADO
28	303360B		Not Available	TOP COVER-DARK COPPERTONE
29	303360G		Not Available	TOP COVER-DARK GOLD
30	303360L		Not Available	TOP COVER-ALMOND
31	303360M		Not Available	TOP COVER-HARVEST WHEAT
32	303360N		Not Available	TOP COVER-FRESH AVOCADO
33	Y303771		Not Available	CHIME ACTUATOR ASSEMBLY
34	304081			Timer Dial
35	304472		Not Available	TEMPERATURE SWITCH
36	Y304473		Not Available	CONTROL SWITCH
37	Y304478		Not Available	PRINTED CIRCUIT BOARD ASSM.
38	Y304671			Button Kit
39	304980			Edgeboard Connector Assembl
40	304984		Not Available	MAIN WIRE HARNESS
41	305187		Not Available	TUMBLER W/BAFFLES
42	Y310632	1163839		Screw
43	Y311423	489483		Screw 10-32 X 1/2
44	Y311660			Chime
45	Y312260		Not Available	LINK
46	312267		Not Available	GLASS - RIGHT
47	Y312268			Glass - Left
48	312273			Nut, Control Knob
49	Y312280			Bearing
50	312282		Not Available	PLATE
51	312852			Selector Knob-Clear Acrylic
52	313823			Control Panel
53	314118	31-4118		Tech Sheet