


# Maytag DG808 02 - FRONT PANEL & DOOR ASSEMBLY



Maytag Residential Maytag DG808 Dryer Parts Parts Diagram 02 - FRONT PANEL & DOOR ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">204439</a>			Screw And Fstner Assembly
2	212949	<a href="#">22001866</a>		Screw, Relay
3	212982	<a href="#">22001650</a>		Fastener, Spring
4	302542		Not Available	PART NOT USED. (DG ONLY)
5	302542H		Not Available	ACCESS DOOR-SHADED GOLD
6	302542K		Not Available	ACCESS DOOR-SHADED AVOCADO
7	302542L		Not Available	PART NOT USED. (DG ONLY)
8	302542M		Not Available	ACCESS DOOR-HARVEST WHEAT
9	302542N		Not Available	ACCESS DOOR-FRESH AVOCADO
10	303942		Not Available	KNOB AND SCREW
11	Y304577	<a href="#">33001230</a>		Hinge, Door
12	Y304579			DOOR (WHT)
13	304579F		Not Available	DOOR-LIGHT GOLD
14	304579J		Not Available	DOOR-LIGHT AVOCADO

15	304579L		Not Available	DOOR-ALMOND
16	304579M		Not Available	DOOR-HARVEST WHEAT
17	304579N		Not Available	DOOR-FRESH AVOCADO
18	<a href="#">304594</a>			Front Panel-White
19	304594H		Not Available	FRONT PANEL-SHADED GOLD
20	304594K		Not Available	FRONT PANEL-SHADED AVOCADO
21	304594L		Not Available	FRONT PANEL-ALMOND
22	304594M	<a href="#">3369903</a>		Dishrack
23	304594N		Not Available	FRONT PANEL-FRESH AVOCADO
24	305835		Not Available	INNER DOOR WITH KNOB & SCRE
25	<a href="#">306436</a>			Door Latch Kit--W
26	<a href="#">Y310376</a>			Clip, Door Switch Harness
27	312301		Not Available	BUSHING FOR ACCESS STUD
28	<a href="#">312369</a>			Sleeve, Access Panel Stud Part Not Used
29	Y313340			LABEL, LINT SCREEN INSTRUCTION
30	<a href="#">Y313907</a>			Fastener, Twin
31	Y313908			DOOR PANEL-WHITE
32	313908F		Not Available	DOOR PANEL-LIGHT GOLD
33	313908J		Not Available	DOOR PANEL-LIGHT AVOCADO
34	313908L		Not Available	DOOR PANEL-ALMOND
35	313908M		Not Available	DOOR PANEL-HARVEST WHEAT
36	313908N		Not Available	DOOR PANEL-FRESH AVOCADO
37	<a href="#">Y313910</a>			Clip, Door Liner To Outer Panel
38	<a href="#">Y313911</a>			Door Strike Retainer
39	Y313927			INSTRUCTION LABEL
40	<a href="#">Y314062</a>			Screw, Door Hinge And Panel
41	<a href="#">314077</a>			Door Seal
42	314119		Not Available	GAS IGNITION LABEL
43	<a href="#">314286</a>			Seal For Front Panel
44	314347	<a href="#">400021-1</a>		Screw
45	Y304576	<a href="#">W10169313</a>		Switch-Dor

*the laundry company*<sup>®</sup>