


# Maytag DG808 03 - FRONT VIEW



Maytag Residential Maytag DG808 Dryer Parts Parts Diagram 03 - FRONT VIEW

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y052740	<a href="#">62739</a>		Nut, Lock
2	<a href="#">204439</a>			Screw And Fstner Assembly
3	<a href="#">204445</a>			Screw And Fastener Assembly
4	<a href="#">210385</a>			Lock Nut For Adjustable Leg
5	<a href="#">210684</a>			Foot, Adjustable Leg
6	<a href="#">210720</a>			Rivet, Bearing To Tumbler Frnt
7	212949	<a href="#">22001866</a>		Screw, Relay
8	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
9	213322		Not Available	MAYTAG DECAL
10	<a href="#">214697</a>			Easy-Grip Knob
11	302542		Not Available	PART NOT USED. (DG ONLY)
12	302542H		Not Available	ACCESS DOOR-SHADED GOLD
13	302542K		Not Available	ACCESS DOOR-SHADED AVOCADO
14	302542L		Not Available	PART NOT USED. (DG ONLY)

15	302542M		Not Available	ACCESS DOOR-HARVEST WHEAT
16	302542N		Not Available	ACCESS DOOR-FRESH AVOCADO
17	Y302699	<a href="#">22003428</a>		Leg, Adjustable
18	303359		Not Available	CABINET-WHITE
19	303359G		Not Available	CABINET-DARK GOLD
20	303359L		Not Available	CABINET-ALMOND
21	303359M		Not Available	CABINET-HARVEST WHEAT
22	303359N		Not Available	CABINET-FRESH AVOCADO
23	303360		Not Available	TOP COVER-WHITE
24	303360A		Not Available	TOP COVER-DARK AVOCADO
25	303360B		Not Available	TOP COVER-DARK COPPERTONE
26	303360G		Not Available	TOP COVER-DARK GOLD
27	303360L		Not Available	TOP COVER-ALMOND
28	303360M		Not Available	TOP COVER-HARVEST WHEAT
29	303360N		Not Available	TOP COVER-FRESH AVOCADO
30	303942		Not Available	KNOB AND SCREW
31	Y304388	<a href="#">33001003</a>		Screen, Lint
32	Y304576	<a href="#">W10169313</a>		Switch-Dor
33	Y304577	<a href="#">33001230</a>		Hinge, Door
34	Y304579			DOOR (WHT)
35	304579F		Not Available	DOOR-LIGHT GOLD
36	304579J		Not Available	DOOR-LIGHT AVOCADO
37	304579L		Not Available	DOOR-ALMOND
38	304579M		Not Available	DOOR-HARVEST WHEAT
39	304579N		Not Available	DOOR-FRESH AVOCADO
40	<a href="#">304594</a>			Front Panel-White
41	304594H		Not Available	FRONT PANEL-SHADED GOLD
42	304594K		Not Available	FRONT PANEL-SHADED AVOCADO
43	304594L		Not Available	FRONT PANEL-ALMOND
44	304594M	<a href="#">3369903</a>		Dishrack
45	304594N		Not Available	FRONT PANEL-FRESH AVOCADO
46	Y304648	<a href="#">33001106</a>		Back, Tumbler
47	<a href="#">Y305086</a>			Adjustable Leg And Nut
48	<a href="#">306436</a>			Door Latch Kit--W
49	312301		Not Available	BUSHING FOR ACCESS STUD
50	<a href="#">312369</a>			Sleeve, Access Panel Stud Part Not Used
51	Y313340			LABEL, LINT SCREEN INSTRUCTION
52	Y313541	<a href="#">33313541</a>		Seal- Tumbler
53	<a href="#">Y313907</a>			Fastener, Twin
54	Y313908			DOOR PANEL-WHITE
55	313908F		Not Available	DOOR PANEL-LIGHT GOLD
56	313908J		Not Available	DOOR PANEL-LIGHT AVOCADO
57	313908L		Not Available	DOOR PANEL-ALMOND
58	313908M		Not Available	DOOR PANEL-HARVEST WHEAT

59	313908N	Not Available	DOOR PANEL-FRESH AVOCADO
60	<a href="#">Y313911</a>		Door Strike Retainer
61	Y313927		INSTRUCTION LABEL
62	<a href="#">Y314062</a>		Screw, Door Hinge And Panel
63	<a href="#">314077</a>		Door Seal
64	<a href="#">Y314137</a>		Foot, Rubber
65	314347	<a href="#">400021-1</a>	Screw

