


Maytag DG810 01 - CONTROL PANEL



18

Maytag Residential Maytag DG810 Dryer Parts Parts Diagram 01 - CONTROL PANEL

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	204807			Ground Wire, Supp. Plte To Top Cover
2	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
3	211168	W10139210		Screw, 8-18 X 5/16
4	213117	67006908		Screw, Ice Rack
5	214806		Not Available	CAP FOR TIMER KNOB
6	214815			End Cap F/Control Panel-LH
7	214816			End Cap F/Control Panel-RH
8	214872			Palnut, End Cap Note: Nut, Lamp Holder
9	214893		Not Available	DETENT RING F/TIMER KNOB CA
10	214894			Fastener, End Cap
11	214897			Pad, Control Panel
12	214990			Button For Switch
13	214991			Button For Switch
14	Y303350		Not Available	SOLENOID

15	Y303771		Not Available	CHIME ACTUATOR ASSEMBLY
16	304964			Wire Connector
17	305194		Not Available	DRYNESS OR PRESS CARE SWITC
18	305196		Not Available	START CONTROL SWITCH NA
19	Y305199			Temperature Selector Switch
20	305201			Auto Dry Or Chime Switch
21	305349		Not Available	MAIN WIRE HARNESS
22	305350	WB48M1		Ov Rack GDE
23	305389		Not Available	EDGEBOARD CONNECTOR ASSEMBL
24	Y305392		Not Available	PRINTED CIRCUIT BOARD
25	305422		Not Available	CONTROL PANEL
26	305451			Timer RPR
27	305869		Not Available	HARNESS ADAPTER WIRE
28	Y311660			Chime
29	Y312260		Not Available	LINK
30	312273			Nut, Control Knob
31	Y313321			Chime Actuator
32	314165		Not Available	CHIME AND SOLENOID BRACKET
33	Y314166			Knob For Timer
34	314167		Not Available	TIMER DIAL INDICATOR
35	314168	313611		Button-DR
36	314184			Back Up Plate
37	Y314322	211251		Screw, Transformer
38	910708	488234		Screw 8-32 X 1/4

the laundry company[®]

PLWS
the laundry company[®]