

Maytag DG8600 03 - FRONT VIEW

SECTION: FRONT VIEW
MODEL: DE-DG MODELS



Issue Date: 6/90

56

Maytag Residential Maytag DG8600 Dryer Parts Parts Diagram 03 - FRONT VIEW
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|--------------------------|---------------|-----------------------------|
| 1 | 307104 | | | Top Cover Assembly |
| " | 204445 | | | Screw And Fastener Assembly |
| 2 | Y305193 | | | Console |
| " | Y313559 | | | Screw |
| 3 | 307124 | | | Cabinet |
| " | Y310632 | 1163839 | | Screw |
| 4 | Y052740 | 62739 | | Nut, Lock |
| 5 | Y305086 | | | Adjustable Leg And Nut |
| 6 | Y314137 | | | Foot, Rubber |
| 7 | Y303361 | | Not Available | BASE ASSY. (UPPER & LOWER) |
| 8 | 302542 | | Not Available | PART NOT USED. (DG ONLY) |
| 9 | Y307998 | | | Front Panel |
| 10 | 307099 | 33001230 | | Hinge, Door |
| 11 | Y307111 | | Not Available | DOOR ASSY. COMPLETE (WHT) |
| 12 | 314966 | | | Panel, Outer |

