


Maytag DG91 01 - CONTROL PANEL & COMPONENTS



Maytag Residential Maytag DG91 Dryer Parts Parts Diagram 01 - CONTROL PANEL & COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	212276	W10116760		Screw
002	213077		Not Available	CAP FOR TIMER KNOB
003	213322		Not Available	MAYTAG DECAL
004	213949			Screw, No.8-18 X 5/16 Inch
005	Y303204			Start Switch With Nuts
006	NLA		Not Available	TOP COVER-WHITE
007	NLA		Not Available	TOP COVER-DARK AVOCADO
008	NLA		Not Available	TOP COVER-DARK COPPERTONE
009	NLA		Not Available	TOP COVER-DARK GOLD
010	NLA		Not Available	TOP COVER-ALMOND
011	NLA		Not Available	TOP COVER-HARVEST WHEAT
012	NLA		Not Available	TOP COVER-FRESH AVOCADO
013	NLA		Not Available	MAIN WIRE HARNESS
014	Y304585			Timer Motor RPR For 305214

014	1304303		Timer Only
015	Y304649	Not Available	TIMER RPR
016	312273		Nut, Control Knob
017	Y312702		Knurled Nut, Start Switch
018	Y312706	422617	Nut
019	NLA	Not Available	BACK COVER FOR 3-3097
020	NLA	Not Available	CONTROL PANEL
021	312751		Lockwasher, Start Switch
022	312852		Selector Knob-Clear Acrylic
023	Y313561		Screw----NA
024	NLA	Not Available	TIMER DIAL
025	NLA	Not Available	HARNES RETAINER

