


MODEL A25CT

CT CONTROL COMPONENTS



2-3357

the laundry company

Maytag [Residential Maytag GA25CT Washer Parts](#) Parts Diagram 04 - CONTROL COMPONENTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	Y201110		Not Available	CONNECTOR, WIRE (INDIC. LIGHT)
NI	NLA		Not Available	JUMPER WIRE (BLACK)
003	202477	22003292		Control As
004	202479	A3167501		Lamp Oven, Int.
NI	202509			Ticket Control Assembly
006	202713	22001555		Fuse
007	203140			Contact Ball Kit
NI	NLA		Not Available	FUSE BLOCK WITH FUSE
"	NLA		Not Available	LAMP SOCKET WITH BRACKET
"	NLA		Not Available	TICKET RECEIVER ASSEMBLY
"	NLA		Not Available	HARNESS FOR TICKET CONTROL
012	204881			Cam Plate Assembly
013	204882		Not Available	SWITCH FOR TICKET CONTROL

NI	NLA		Not Available	DOUBLE MELT CLIP W/DEFLECTO
"	NLA		Not Available	SPADE CONNECTOR
016	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
017	211737	248562		Terminal
NI	NLA		Not Available	OVERLAY FOR CIRCUIT BOARD
019	212452			Board, Circuit
NI	NLA		Not Available	SEMS SCREW (No.4-40 X 1/2 INC)
021	212519	488234		Screw 8-32 X 1/4
022	212533			SHIELD FOR HEAT LAMP
NI	NLA		Not Available	SCREW, SHIELD TO CONTROL
"	NLA		Not Available	FRONT PLATE F/TICKET CONTRO
"	NLA		Not Available	BRACKET FOR TICKET ASSEMBLY
026	213074			Pin Receptacle For Plug
NI	NLA		Not Available	PIN FOR PLUG
"	NLA		Not Available	TICKET DEFLECTOR
"	NLA		Not Available	SCREW (No.6 X 1/4 INCH)
"	NLA		Not Available	SHIELD
031	214218			Lever, Switch
032	214220			Adjustment Thumb Wheel
033	214275			Roller For Cam
NI	NLA		Not Available	SCREW
"	NLA		Not Available	SPRING WASHER
036	Y311550		Not Available	SPADE (MINIATURE)
037	311612		Not Available	COVER, CIRCUIT BOARD TERMINALS
038	311613	Y311711		Screw, Fuse Block

