


Maytag GA26CDC 04 - CABINET



8

Maytag [Residential Maytag GA26CDC Washer Parts](#) Parts Diagram 04 - CABINET
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	200961	12001413		Strainer And Washer Kit
002	205828	202860		Inlet Hose Assembly
003	Y013783			Washer, Inlet Hose
004	Y313561			Screw----NA
005	212276	W10116760		Screw
006	214812	22002361		Bracket, Water Valve
007	201575			Clamp, Hose
008	214337	96160		Screen
009	205614	205613		Water Valve
010	NLA		Not Available	PLATE, ACCESS
011	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
012	212985	22002924		Plate, Access
013	NLA		Not Available	CABINET-WHITE
014	213121	3400111		Screw, 12-14 X 5/8
015	213007			Xfor Cabinet See Cabinet, Back

016	204439		Screw And Fstner Assembly
017	213846		Guard, Belt
018	212998	Not Available	PANEL, FRONT (WHT)
"	212998L	Not Available	FRONT PANEL-ALMOND
"	NLA	Not Available	FRONT PANEL-HARVEST WHEAT
019	212982	22001650	Fastener, Spring
020	214376	22002331	Spacer, Front Panel
021	215058		Pad, Cabinet Bumper
022	214768	211704	Hose, Drain
023	200461	285655	Clamp, Hose
024	211111	16272	Connector, Straight
025	215057	211704	Hose, Drain

the laundry company[®]

the laundry company[®]

the laundry company[®]