


MODELS A283-A284

CONTROL PANEL



Maytag Residential Maytag GA284 Washer Parts Parts Diagram 04 - CONTROL PANEL

Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|------------------------|---------------------------|---------------|---|
| 1 | 205033 | 22205033 | | Motor- Tim |
| 2 | 206216 | | | Water Temperature Switch |
| 3 | 206217 | | Not Available | SPEED CONTROL SWITCH |
| 4 | 206221 | | Not Available | WATER LEVEL SWITCH----NA |
| 5 | 206225 | | | Timer |
| 6 | 206850 | | Not Available | CONTROL PANEL |
| 7 | 210932 | | | Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct |
| 8 | 211065 | | | Spring, Index Wheel |
| 9 | 211168 | W10139210 | | Screw, 8-18 X 5/16 |
| 10 | 211605 | | | Bezel, Timer Dial |
| 11 | 213117 | 67006908 | | Screw, Ice Rack |
| 12 | 213966 | 3400014 | | Screw |
| 13 | 214815 | | | End Cap F/Control Panel-LH |
| 14 | 214816 | | | End Cap F/Control Panel-RH |
| 15 | 214818 | | | Back Up Plate |

| | | | |
|----|------------------------|--------------------------|-------------------------------------|
| NI | 214869 | | Clip For Back Up Plate |
| 17 | 214872 | | Nut, End Cap Note: Nut, Lamp Holder |
| 18 | 214894 | | Fastener, End Cap |
| 19 | 214897 | | Pad, Control Panel |
| 20 | 215161 | 22001571 | Bezel, Timer Dial |
| 21 | 215162 | | Timer Knob |
| 22 | 215163 | Not Available | CAP FOR KNOB |

