



Maytag [Residential Maytag GA308 Washer Parts](#) Parts Diagram 03 - ELECTRICAL COMPONENTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	<a href="#">Y200832</a>			Capacitor
"	201805	<a href="#">12002351</a>		Motor-Drve
"	203235		Not Available	WIRE HARNESS - FILL
"	<a href="#">203237</a>			No. 17 Wire With Terminal
"	<a href="#">204590</a>			Cord, Power
"	<a href="#">204968</a>			Plunger And Bracket Assembly--W
"	<a href="#">205001</a>			Timer
"	<a href="#">205006</a>			Major Wire Harness
"	205033	<a href="#">22205033</a>		Motor- Tim
"	205166		Not Available	TIMER DIAL, SUN-GLOW
"	<a href="#">205320</a>			Temperature Control Switch
"	<a href="#">205336</a>			Water Level Switch
"	205410		Not Available	TIMER MOTOR 120-60
"	205415	<a href="#">279347</a>		Switch-Lid
"	<a href="#">205613</a>			Water Valve
"	<a href="#">206103</a>			Capacitor Kit

"	210186	<a href="#">3370225</a>	Screw
"	<a href="#">210866</a>		Nut, Twin Speed
"	<a href="#">211065</a>		Spring, Index Wheel
"	<a href="#">211149</a>		Clip, Capacitor
"	<a href="#">211500</a>		Washer, Bracket To Top Cover
"	<a href="#">211605</a>		Bezel, Timer Dial
"	211737	<a href="#">248562</a>	Terminal
"	<a href="#">211881</a>		Grommet, Cord Part Not Used- Gas Models Only
"	212937	Not Available	BARRIER, MOISTURE
"	213077	Not Available	CAP FOR TIMER KNOB
"	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
"	<a href="#">213718</a>		Plunger, Lid Switch
"	213719	Not Available	LEVER, UNBALANCE
"	<a href="#">213720</a>		Spring, Lid Switch
"	214196	Not Available	TIMER KNOB-CLEAR ACRYLIC
"	214337	<a href="#">96160</a>	Screen
"	<a href="#">301548</a>		Clamp, Ground Wire
"	303846	<a href="#">22003781</a>	Screw, Ground Strap
35	<a href="#">311155</a>		Ground Wire And Clamp
36	<a href="#">313122</a>		Screw - Baffle To Tumbler
37	Y313262	<a href="#">W10116752</a>	Retainer-
38	910182	<a href="#">25-7809</a>	Screw, No.6-20 1/2 Flthd Torx

**Howes**  
the laundry company®

**Howes**  
the laundry company®