


Maytag GA308 05 - REAR VIEW



Maytag Residential Maytag GA308 Washer Parts Parts Diagram 05 - REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	Y201808			Converter
4	203172M		Not Available	TOP COVER-HARVEST WHEAT
7	203319M		Not Available	CABINET-HARVEST WHEAT
8	204590			Cord, Power
9	205192		Not Available	CONTROL PANEL, SUN-GLOW
10	205197		Not Available	CONTROL PANEL KIT, SUN-GLOW
11	205613			Water Valve
12	210385			Lock Nut For Adjustable Leg
13	210684			Foot, Adjustable Leg
14	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
15	211878		Not Available	PLATE, ACCESS
16	211881			Grommet, Cord Part Not Used-Gas Models Only
17	212276	W10116760		Screw

18	212277		Screw, No.8 X 1/2 Inch
19	212984		Valve Mounting Plate
20	212985	22002924	Plate, Access
23	213009M		Not Available
24	213121	3400111	Screw, 12-14 X 5/8
25	214135		Not Available
26	214337	96160	Screen
27	214519		LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
NI	301548		Clamp, Ground Wire
29	Y302699	22003428	Leg, Adjustable
31	311155		Ground Wire And Clamp
"	312620		Screw, Sems

the laundry company[®]

the laundry company[®]

the laundry company[®]