


# Maytag GA308S 05 - ELECTRICAL COMPONENTS



Maytag [Residential Maytag GA308S Washer Parts](#) Parts Diagram 05 - ELECTRICAL COMPONENTS  
 Click on the part number to view part

| Item | Original Part Number    | Replaced By              | Status        | Part Description                |
|------|-------------------------|--------------------------|---------------|---------------------------------|
| 1    | <a href="#">200806</a>  |                          |               | Solenoid                        |
| NI   | <a href="#">Y200832</a> |                          |               | Capacitor                       |
| 3    | <a href="#">201168</a>  |                          |               | Diverter Valve                  |
| 4    | 201805                  | <a href="#">12002351</a> |               | Motor-Drve                      |
| NI   | 203235                  |                          | Not Available | WIRE HARNESS - FILL             |
| 6    | 203236                  |                          | Not Available | WIRE HARNESS - SUDS SAVE        |
| NI   | <a href="#">203237</a>  |                          |               | No.17 Wire With Terminal        |
| 8    | <a href="#">204590</a>  |                          |               | Cord, Power                     |
| 9    | <a href="#">204968</a>  |                          |               | Plunger And Bracket Assembly--W |
| 10   | 205002                  | <a href="#">22205002</a> |               | Timer                           |
| 11   | <a href="#">205006</a>  |                          |               | Major Wire Harness              |
| NI   | 205033                  | <a href="#">22205033</a> |               | Motor- Tim                      |
| 13   | 205165                  |                          | Not Available | TIMER DIAL, SUN-GLOW            |
| 14   | <a href="#">205320</a>  |                          |               | Temperature Control Switch      |
| 15   | <a href="#">205321</a>  |                          |               | Temperature Control Switch      |

|    |                        |                           |   |
|----|------------------------|---------------------------|---|
| 16 | <a href="#">205336</a> |                           | Water Level Switch                              |
| NI | 205410                 | Not Available             | TIMER MOTOR 120-60                              |
| 18 | 205415                 | <a href="#">279347</a>    | Switch-Lid                                      |
| 19 | <a href="#">205613</a> |                           | Water Valve                                     |
| NI | <a href="#">206103</a> |                           | Capacitor Kit                                   |
| 21 | 210186                 | <a href="#">3370225</a>   | Screw   |
| 22 | <a href="#">210866</a> |                           | Nut, Twin Speed                                 |
| 23 | <a href="#">211065</a> |                           | Spring, Index Wheel                             |
| NI | <a href="#">211149</a> |                           | Clip, Capacitor                                 |
| 25 | <a href="#">211500</a> |                           | Washer, Bracket To Top Cover                    |
| 26 | <a href="#">211605</a> |                           | Bezel, Timer Dial                               |
| 27 | 211737                 | <a href="#">248562</a>    | Terminal  |
| 28 | <a href="#">211881</a> |                           | Grommet, Cord Part Not Used-<br>Gas Models Only |
| 29 | 212937                 | Not Available             | BARRIER, MOISTURE                               |
| 30 | 213077                 | Not Available             | CAP FOR TIMER KNOB                              |
| 31 | <a href="#">213501</a> |                           | Screw, No.6-20 X 1-1/8 Inch                     |
| 32 | <a href="#">213718</a> |                           | Plunger, Lid Switch                             |
| 33 | 213719                 | Not Available             | LEVER, UNBALANCE                                |
| 34 | <a href="#">213720</a> |                           | Spring, Lid Switch                              |
| 35 | 214196                 | Not Available             | TIMER KNOB-CLEAR<br>ACRYLIC                     |
| 36 | 214337                 | <a href="#">96160</a>     | Screen  |
| 37 | <a href="#">301548</a> |                           | Clamp, Ground Wire                              |
| 38 | 303846                 | <a href="#">22003781</a>  | Screw, Ground Strap                             |
| 39 | <a href="#">311155</a> |                           | Ground Wire And Clamp                           |
| 40 | <a href="#">313122</a> |                           | Screw - Baffle To Tumbler                       |
| 41 | Y313262                | <a href="#">W10116752</a> | Retainer-                                       |
| 42 | 910182                 | <a href="#">25-7809</a>   | Screw, No.6-20 1/2 Flthd Torx                   |

