


# Maytag GA382 08 - TRANSMISSION-ORBITAL



24

Maytag [Residential Maytag GA382 Washer Parts](#) Parts Diagram 08 - TRANSMISSION-ORBITAL  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	206707	<a href="#">6-2097750</a>		Trans Dee
2	207153	<a href="#">6-2097820</a>		Kit- Shaft
3	206713	<a href="#">6-2067130</a>		Gear- Beve
4	<a href="#">215581</a>			Spring, Agitator Shaft
5	206685	<a href="#">6-2066850</a>		Yoke
6	<a href="#">206628</a>			Cover, Transmission
7	215417		Not Available	SCREW, TRANSMISSION COVER
8	215415		Not Available	COLLAR, LOWER
9	215401	<a href="#">W10221114</a>		Pinion
10	<a href="#">215395</a>			Plate, Clutch
11	211483	<a href="#">6-2114830</a>		Washer- SP
12	<a href="#">Y206629</a>			Pin, Collar
13	215410	<a href="#">12001450</a>		Ctr Shaft W/Collar Andkeeper- Dp
14	211059	<a href="#">6-2301530</a>		Pulley
15	<a href="#">211089</a>			Lug, Stop Pulley

16	211375	<a href="#">681582</a>	Screw
17	211090	<a href="#">22003555</a>	Washer, Stop Lug
18	206602	<a href="#">207843</a>	Lip Seal Repair Kit
19	<a href="#">215394</a>		Washer, Bevel Gear
20	206624	<a href="#">6-2097750</a>	Trans Dee
21	Y058700	<a href="#">675652</a>	Adhesive
22	<a href="#">210690</a>		Seal, Rubber
25	<a href="#">215733</a>		Dispensing Cup
28	206478	Not Available	SCREW & WASHER FOR AGITATOR

