


Maytag GA482 09 - TUB-INNER & OUTER



20

Maytag Residential Maytag GA482 Washer Parts Parts Diagram 09 - TUB-INNER & OUTER
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211100			Washer, Outer Tub
2	Y054867			Washer, Lock
3	204013	6-2040130		Tub Bearin
4	200824	6-2040130		Tub Bearin
5	211130			Bearing Liner, Tub Bearing
6	201537	6-2095720		Mounting S
7	204012	6-2095720		Mounting S
8	211618	22001423		Set Screw, Mounting Stem
9	202521	6-2095720		Mounting S
10	211047	6-2110472		Nut- Clamp
11	Y0A4298	6-0A57420		Seal- Agitator
12	Y015667			Retaining Ring
13	Y015666			Washer, Retaining -
14	211210			Washer, Clamping Nut
15	207831		Not Available	TUB, INNER (W/PLUG)
16	205484			Tub, Outer Part Not Used

18	214434		Spout, Deflector
19	214739	596669	Clamp, Manifold
20	205161	489503	Clamp
21	214725		Cap For Spout-Outer Tub
22	200461	285655	Clamp, Hose
23	213045		Hose, Outer Tub Part Not Used
24	200900	616099	Clamp
25	211641		Clamp, 1-1/16"
26	200744	W10175939	Bolt
"	205254	W10175938	Bolt
27	212942	22001619	Tube, Water Level Switch
28	410296	596669	Clamp, Manifold
29	215980		Plug, Filter Hole

the laundry company[®]

the laundry company[®]

the laundry company[®]