


# Maytag GA490 04 - CONTROL PANEL



6

Maytag [Residential Maytag GA490 Washer Parts](#) Parts Diagram 04 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">206231</a>			Wire Harness
2	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
3	206220		Not Available	WATER LEVEL SWITCH
4	410296	<a href="#">596669</a>		Clamp, Manifold
5	212942	<a href="#">22001619</a>		Tube, Water Level Switch
6	205033	<a href="#">22205033</a>		Motor- Tim
7	<a href="#">206230</a>			Timer
8	213117	<a href="#">67006908</a>		Screw, Ice Rack
9	<a href="#">215211</a>			Button For Switch
10	<a href="#">206216</a>			Water Temperature Switch
11	215213	<a href="#">214993</a>		Button For Switch
"	<a href="#">215212</a>			Button For Switch
12	<a href="#">214897</a>			Pad, Control Panel
13	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
14	<a href="#">210932</a>			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct

15	<a href="#">214816</a>		End Cap F/Control Panel-RH
16	<a href="#">214894</a>		Fastener, End Cap
17	213966	<a href="#">3400014</a>	Screw
18	<a href="#">211065</a>		Spring, Index Wheel
19	<a href="#">211605</a>		Bezel, Timer Dial
20	215164	Not Available	CAP FOR KNOB
21	<a href="#">215162</a>		Timer Knob
22	215161	<a href="#">22001571</a>	Bezel, Timer Dial
23	<a href="#">214818</a>		Back Up Plate
24	206571	Not Available	CONTROL PANEL
25	<a href="#">214815</a>		End Cap F/Control Panel-LH

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>