


Maytag GA608S 11 - POWER UNIT & CENTER ASSEMBLY



Maytag Residential Maytag GA608S Washer Parts Parts Diagram 11 - POWER UNIT & CENTER ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y0A4298	6-0A57420		Seal- Agitator
2	14792	WH1X2296		Friction Pad
3	Y014827			Washer-Center Shaft
4	Y014839			Collar-Drive Shaft
5	Y015149			Brass Washer-Agitator Seal
6	Y015494			Stop Ring-Agitator Shaft
7	Y015629			Bolt, Grinding Chamber
8	015639			Dowel Pin
9	Y015666			Washer, Retaining -
10	Y015667			Retaining Ring
11	Y015902			Spring For Agitator
12	038313	22038313		Wrench, Spanner
13	Y038555			Tool-Install Center Shaft
14	Y054867			Washer, Lock
15	Y056016			Center Seal Grease
16	Y056080	6-0560800		Oil

17	200730	22002124		Shaft- Agi
18	200813		Not Available	GEAR CASE COVER ASSEMBLY
19	200824	6-2040130		Tub Bearin
20	201463		Not Available	PITMAN WITH WRIST PIN
21	201537	6-2095720		Mounting S
22	202521	6-2095720		Mounting S
23	203193		Not Available	GEAR HOUSING W/STUDS & TUBE
24	203438	W10172457		Transmison
25	203775			Ctn 10 Auto Trans Lube
26	204012	6-2095720		Mounting S
27	204013	6-2040130		Tub Bearin
28	204967			Gear Kit-Power Fin Agitator
29	210054			Pinion
30	210179			Retaining Ring
31	210183			Groove Pin
32	210286			Seal
33	210315			Pinion
34	210632	22210632		Gasket
35	210670			Segment
36	210690			Seal, Rubber
37	211022		Not Available	BEARING
38	211028	22001586		Deflector, Water
39	211047	6-2110472		Nut- Clamp
40	211089			Lug, Stop Pulley
41	211090	22003555		Washer, Stop Lug
42	211100			Washer, Outer Tub
43	211130			Bearing Liner, Tub Bearing
44	211210			Washer, Clamping Nut
45	211375	681582		Screw
46	211483	6-2114830		Washer- SP
47	211484			Washer, Lug
48	211486			Screw, 3/8-16 X 1/2 Inch
49	211487			Groov-Pin
50	211618	22001423		Set Screw, Mounting Stem
52	213044			Shaft, Center
53	213068	204967		Gear Kit-Power Fin Agitator
54	214276		Not Available	WASHER FOR GEARS