


Maytag GA7500 02 - CONTROL PANEL

SECTION: CONTROL PANEL
 MODEL: A7500 A7500S A7500W SERIES 01



Issue Date: 7/91

12

[Maytag Residential Maytag GA7500 Washer Parts Parts Diagram 02 - CONTROL PANEL](#)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	214809			Back Up Plate
"	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
3	215821		Not Available	CAP, KNOB
4	410296	596669		Clamp, Manifold
5	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
6	214897			Pad, Control Panel
7	207215		Not Available	END CAP LH
8	207216		Not Available	END CAP RH
9	214894			Fastener, End Cap
10	211168	W10139210		Screw, 8-18 X 5/16
"	207362		Not Available	INFINITE LEVEL PRESSURE SWITCH
11	214872			Palnut, End Cap Note: Nut, Lamp Holder
12	211605			Bezel, Timer Dial
13	211065			Spring, Index Wheel

14	207365		2 Button Switch
"	211168	W10139210	Screw, 8-18 X 5/16
15	213966	3400014	Screw
16	215827		Not Available
			TIMER DIAL SKIRT
17	215828		Knob, Timer
18	205033	22205033	Motor- Tim
19	213117	67006908	Screw, Ice Rack
"	207367		Not Available
			TEMP CONTROL SWITCH - 4 BUTTON

