


# Maytag GA8100 04 - CONTROL PANEL

SECTION: CONTROL PANEL  
MODEL: A8100



Issue Date: 6/90

16

Maytag [Residential Maytag GA8100 Washer Parts](#) Parts Diagram 04 - CONTROL PANEL  
Click on the part number to view part

| Item | Original Part Number   | Replaced By              | Status        | Part Description                                   |
|------|------------------------|--------------------------|---------------|--|
| 1    | 212942                 | <a href="#">22001619</a> |               | Tube, Water Level Switch                           |
| 2    | <a href="#">214818</a> |                          |               | Back Up Plate                                      |
| "    | <a href="#">210932</a> |                          |               | Screw, No.8 X 9/16 Ctsk Note:<br>Screw, Inlet Duct |
| 3    | 215821                 |                          | Not Available | CAP, KNOB  |
| 4    | 410296                 | <a href="#">596669</a>   |               | Clamp, Manifold                                    |
| 5    | 207606                 |                          | Not Available | CONTROL PANEL                                      |
| "    | <a href="#">210932</a> |                          |               | Screw, No.8 X 9/16 Ctsk Note:<br>Screw, Inlet Duct |
| 6    | <a href="#">214897</a> |                          |               | Pad, Control Panel                                 |
| 7    | 207215                 |                          | Not Available | END CAP LH   |
| 8    | 207216                 |                          | Not Available | END CAP RH   |
| 9    | <a href="#">214894</a> |                          |               | Fastener, End Cap                                  |
| 10   | <a href="#">214872</a> |                          |               | Palnut, End Cap Note: Nut,<br>Lamp Holder          |
| 11   | <a href="#">211605</a> |                          |               | Bezel, Timer Dial                                  |
| 12   | <a href="#">211065</a> |                          |               | Spring, Index Wheel                                |

|    |                        |                           |                                |
|----|------------------------|---------------------------|--------------------------------|
| 13 | 213966                 | <a href="#">3400014</a>   | Screw                          |
| "  | <a href="#">207379</a> |                           | Timer                          |
| 14 | 215827                 | Not Available             | TIMER DIAL SKIRT               |
| 15 | <a href="#">215828</a> |                           | Knob, Timer                    |
| 16 | 205033                 | <a href="#">22205033</a>  | Motor- Tim                     |
| 17 | 207363                 | Not Available             | 3 LEVEL PRESSURE SWITCH        |
| "  | 211168                 | <a href="#">W10139210</a> | Screw, 8-18 X 5/16             |
| 18 | 213117                 | <a href="#">67006908</a>  | Screw, Ice Rack                |
| "  | 207368                 | Not Available             | TEMP CONTROL SWITCH - 3 BUTTON |
| 19 | <a href="#">207383</a> |                           | Wire Harness                   |

**Howes**  
the laundry company®

**Howes**  
the laundry company®

**Howes**  
the laundry company®