


Maytag GA8500 04 - CONTROL PANEL

SECTION: CONTROL PANEL
MODEL: A8500



Issue Date: 4/90

8

Maytag [Residential Maytag GA8500 Washer Parts](#) Parts Diagram 04 - CONTROL PANEL

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	212942	22001619		Tube, Water Level Switch
2	214818			Back Up Plate
3	215821		Not Available	CAP, KNOB
4	410296	596669		Clamp, Manifold
5	207604		Not Available	CONTROL PANEL
6	214897			Pad, Control Panel
7	207215		Not Available	END CAP LH
8	207216		Not Available	END CAP RH
9	214894			Fastener, End Cap
10	214872			Palnut, End Cap Note: Nut, Lamp Holder
11	211605			Bezel, Timer Dial
12	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
13	211168	W10139210		Screw, 8-18 X 5/16
14	213117	67006908		Screw, Ice Rack
15	213966	3400014		Screw

16	211065		Spring, Index Wheel
17	207379		Timer
18	215827	Not Available	TIMER DIAL SKIRT
19	215828		Knob, Timer
20	205033	22205033	Motor- Tim
21	207361		4 Level Pressure Switch
22	207368	Not Available	TEMP CONTROL SWITCH - 3 BUTTON
23	207383		Wire Harness

