


# Maytag GA884 04 - CONTROL PANEL

Section: CONTROL PANEL

P/N 1600021

Models: A590 A884



11/91

10

Maytag [Residential Maytag GA884 Washer Parts](#) Parts Diagram 04 - CONTROL PANEL

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	206234		Not Available	WIRE HARNESS
2	206220		Not Available	WATER LEVEL SWITCH
3	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
4	410296	<a href="#">596669</a>		Clamp, Manifold
5	212942	<a href="#">22001619</a>		Tube, Water Level Switch
6	<a href="#">206614</a>			Fabric Control Switch
7	213117	<a href="#">67006908</a>		Screw, Ice Rack
8	206217		Not Available	SPEED CONTROL SWITCH
9	<a href="#">215211</a>			Button For Switch
10	205033	<a href="#">22205033</a>		Motor- Tim
11	<a href="#">206225</a>			Timer
12	<a href="#">215211</a>			Button For Switch
13	<a href="#">206216</a>			Water Temperature Switch
14	<a href="#">215212</a>			Button For Switch
"	215213	<a href="#">214993</a>		Button For Switch
15	<a href="#">214897</a>			Pad, Control Panel

16	<a href="#">214872</a>		Palnut, End Cap Note: Nut, Lamp Holder
17	<a href="#">210932</a>		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
18	<a href="#">214816</a>		End Cap F/Control Panel-RH
19	<a href="#">214894</a>		Fastener, End Cap
20	213966	<a href="#">3400014</a>	Screw
21	<a href="#">211065</a>		Spring, Index Wheel
22	<a href="#">211605</a>		Bezel, Timer Dial
23	215163	Not Available	CAP FOR KNOB
24	<a href="#">215162</a>		Timer Knob
25	215161	<a href="#">22001571</a>	Bezel, Timer Dial
26	<a href="#">214809</a>		Back Up Plate
27	206774	Not Available	CONTROL PANEL
28	<a href="#">214815</a>		End Cap F/Control Panel-LH

