


Maytag GA9900 04 - CONTROL PANEL

SECTION: CONTROL PANEL
MODEL: A9900



Issue Date: 4/90

32

Maytag Residential Maytag GA9900 Washer Parts Parts Diagram 04 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	212942	22001619		Tube, Water Level Switch
2	215722			Backup Plate
3	215725		Not Available	BRACKET RELAY
4	215720		Not Available	BRACKET FOR WATER LEVEL SW
5	207208			Pc Board
6	410296	596669		Clamp, Manifold
7	207220		Not Available	CONTROL PANEL
8	214897			Pad, Control Panel
9	207215		Not Available	END CAP LH
10	207216		Not Available	END CAP RH
11	214894			Fastener, End Cap
12	912077			Locknut, Reader Harness
13	207235		Not Available	MOUNTING PANEL ASSY
14	214872			Palnut, End Cap Note: Nut, Lamp Holder
15	206421			Relay, Motor Reversing

16	207770		Not Available	RELAY
17	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
18	212949	22001866		Screw, Relay
NI	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
20	Y313559			Screw
21	Y311711			Screw, Fuse Block
22	910647	489355		Screw, 8 X 1/2
"	910647	489355		Screw, 8 X 1/2
23	207170M		Not Available	TOP COVER ASSY HVT WHEAT
24	207766			Transformer
25	207213		Not Available	WATER LEVEL SWITCH
26	207218		Not Available	WIRE HARNESS
27	207211		Not Available	WIRE HARNESS
28	207212		Not Available	WIRE HARNESS

