


Maytag GDE18CA 03 - REAR VIEW



Maytag [Residential Maytag GDE18CA Dryer Parts](#) Parts Diagram 03 - REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	210385			Lock Nut For Adjustable Leg
NI	210684			Foot, Adjustable Leg
004	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
005	211881			Grommet, Cord Part Not Used-Gas Models Only
NI	NLA		Not Available	CONTROL COVER-WHITE
"	NLA		Not Available	CONTROL COVER-HARVEST WHEAT
008	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
009	Y302699	22003428		Leg, Adjustable
NI	NLA		Not Available	CONTROL CENTER-WHITE
"	NLA		Not Available	CABINET-WHITE
"	NLA		Not Available	CABINET-ALMOND
"	NLA		Not Available	CABINET-HARVEST WHEAT
"	Y303361		Not Available	BASE ASSY. (UPPER &

		Not Available	LOWER)
"	NLA	Not Available	TOP COVER-WHITE
"	NLA	Not Available	TOP COVER-ALMOND
"	NLA	Not Available	TOP COVER-HARVEST WHEAT
"	Y303442		EXHAUST DUCT ASSEMBLY
"	NLA	Not Available	SCREW & WASHER ASSY.
"	NLA	Not Available	CONTROL COVER-WHITE
"	NLA	Not Available	CONTROL COVER-ALMOND
"	NLA	Not Available	CONTROL COVER-HARVEST WHEAT
023	Y305086		Adjustable Leg And Nut
024	310557		Washer
025	Y310632	1163839	Screw
NI	NLA	Not Available	BACK FOR CONTROL PANEL
027	Y313559		Screw
028	Y313561		Screw---NA
029	Y314137		Foot, Rubber

