


Maytag GDE23CD 02 - REAR VIEW



Maytag Residential Maytag GDE23CD Dryer Parts Parts Diagram 02 - REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	210385			Lock Nut For Adjustable Leg
003	210684			Foot, Adjustable Leg
004	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
005	213007			Xfor Cabinet See Cabinet, Back
006	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
007	301548			Clamp, Ground Wire
008	Y302699	22003428		Leg, Adjustable
NI	NLA		Not Available	SCREW & WASHER ASSY.
010	Y305087	22003544		Adjustable Leg W/Foot And Nut
011	Y305190	307104		Top Cover Assembly
NI	NLA		Not Available	(ALM)
"	NLA		Not Available	(H. WHEAT)

"	NLA	Not Available	CABINET (WHT)
"	NLA	Not Available	(ALM)
"	NLA	Not Available	(H. WHEAT)
"	NLA	Not Available	COUPLING COLLAR (WHT)
"	NLA	Not Available	(ALM)
"	NLA	Not Available	(H. WHEAT)
020	Y310632	1163839	Screw
021	310933	33002194	Nut, Speed
022	311155		Ground Wire And Clamp
023	Y311423	489483	Screw 10-32 X 1/2
024	311484	112432	Nut
025	Y312184		Strap, Grounding
026	Y312209	W10001200	Screw
027	Y312904		Bracket, Terminal Block
028	Y312905	Not Available	COVER, TERMINAL
029	Y312951	Not Available	ACCESS COVER, BACK
030	313122		Screw - Baffle To Tumbler
031	Y313559		Screw
032	Y313561		Screw---NA
NI	NLA	Not Available	TOP COVER PLATE
"	314663	214354	Screw, Top Cover To Cabnt.
035	400008		Block, Terminal

