


Maytag GDE24CS 02 - CS CONTROL PANEL/COIN BOX



+Contact your commercial laundry distributor for locks and keys.

Maytag [Residential Maytag GDE24CS Dryer Parts](#) Parts Diagram 02 - CS CONTROL PANEL/COIN BOX
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052634	701719		Nut, Hex
002	Y052721			Nut, Terminal Block Plate
003	Y052740	62739		Nut, Lock
004	203188		Not Available	TIMER ACCESS DOOR (WHT)
005	203188L		Not Available	ACCESS DOOR-ALMOND
006	203188M		Not Available	ACCESS DOOR-HARVEST WHEAT
NI	NLA		Not Available	MTG. STRAP---NA
008	205423	208883		Coin Box K
009	205423L	208883		Coin Box K
010	205423M	208883		Coin Box K
011	206956	22001405		Case, Coin Slide
012	206956L	22001405		Case, Coin Slide
013	206956M	22001405		Case, Coin Slide
014	211065			Spring, Index Wheel
015	211168	W10139210		Screw, 8-18 X 5/16

016	211790			Lock Ring For Timer Shaft
017	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
018	212328	W10139762		Hex Nut, 3/4-27
019	212707	3196385		Screw
020	213750	W10133266		Cam-Lock
021	214648			Decal, Coinage
022	214660			Gasket, Control Center
023	215559			Bolt, Coin Slide Locking
024	305796			Timer
025	305797			Torsion Timer Assembly Complete
026	305798		Not Available	BYPASS SWITCH FOR MOTOR
027	Y305799			Bypass Switch For Heater
028	305800			Wire Harness For Timer
029	305813			Part Not Available Part Not Used
030	305870			Timer Motor
031	306104			Actuator Switch Kit
032	Y312270			Clip, Spring Retainer
033	314330		Not Available	DRIVER FOR INDEX WHEEL (NOT INCLUDED W/KIT)
034	314331			Spring, Torsion Return
035	314332			Spring, Actuator
036	314333			Timer Mounting Bracket
037	314334			Bracket For Coin Slide
038	314335			Peg, Tine Adjustment
039	314337	33002968		Slider
040	314339			Switch And Slider Bracket
NI	NLA		Not Available	HELICAL SPRING ----N
"	NLA		Not Available	INSTRUCTION LABEL
"	NLA		Not Available	SCREW
"	NLA		Not Available	STOP FOR TIMER MECHANISM
045	314546			Wheel, Index
046	314547	Y308109		Slide And Adj. Return Bracket
047	314548	33002967		Actuator, Switch
048	910309			Washer, Mounting Strap
049	910387			Lockwasher, Vault Assembly
050	910708	488234		Screw 8-32 X 1/4