


Maytag GDE24CS 05 - REAR VIEW



Maytag [Residential Maytag GDE24CS Dryer Parts](#) Parts Diagram 05 - REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	Y201808			Converter
003	204439			Screw And Fstner Assembly
004	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
005	211881			Grommet, Cord Part Not Used-Gas Models Only
006	212276	W10116760		Screw
007	213007			Xfor Cabinet See Cabinet, Back
008	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
009	301548			Clamp, Ground Wire
010	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
011	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
NI	NLA		Not Available	SCREW & WASHER ASSY.

"	NLA		Not Available	FRONT PANEL-WHITE
"	NLA		Not Available	FRONT PANEL-ALMOND
"	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
"	Y305086			Adjustable Leg And Nut
"	305168	33002916		Power Cord, Canadian 240V
"	Y305191		Not Available	TOP COVER-WHITE
"	NLA		Not Available	TOP COVER-ALMOND
"	NLA		Not Available	TOP COVER-HARVEST WHEAT
"	NLA		Not Available	CONSOLE-WHITE
"	NLA		Not Available	CONSOLE-ALMOND
"	NLA		Not Available	CONSOLE-HARVEST WHEAT
"	NLA		Not Available	CABINET-WHITE
"	NLA		Not Available	CABINET-ALMOND
"	NLA		Not Available	CABINET-HARVEST WHEAT
"	NLA		Not Available	CONTROL COVER (WHT)
"	NLA		Not Available	CONTROL COVER ASSY----NA
"	NLA		Not Available	CONTROL COVER ASSY
"	Y310632	1163839		Screw
"	311155			Ground Wire And Clamp
"	Y311270			Washer, Terminal Block
033	Y311423	489483		Screw 10-32 X 1/2
034	311484	112432		Nut
035	Y312184			Strap, Grounding
036	Y312209	W10001200		Screw
037	Y312904			Bracket, Terminal Block
038	Y312905		Not Available	COVER, TERMINAL
039	Y312951		Not Available	ACCESS COVER, BACK
040	313122			Screw - Baffle To Tumbler
041	Y313559			Screw
042	Y313561			Screw----NA
043	Y314137			Foot, Rubber
044	400008			Block, Terminal

