


Maytag GDE24CT 03 - CT CONTROL CENTER COMPONENTS



2-3357

Maytag [Residential Maytag GDE24CT Dryer Parts](#) Parts Diagram 03 - CT CONTROL CENTER COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y201110		Not Available	CONNECTOR, WIRE (INDIC. LIGHT)
NI	NLA		Not Available	JUMPER WIRE (BLACK)
003	202477	22003292		Control As
004	202479	A3167501		Lamp Oven, Int.
NI	202509			Ticket Control Assembly
006	202713	22001555		Fuse
007	203140			Contact Ball Kit
NI	NLA		Not Available	FUSE BLOCK WITH FUSE
"	NLA		Not Available	LAMP SOCKET WITH BRACKET
"	NLA		Not Available	TICKET RECEIVER ASSEMBLY
"	NLA		Not Available	HARNESS FOR TICKET CONTROL
012	204881			Cam Plate Assembly
013	204882		Not Available	SWITCH FOR TICKET CONTROL

NI	NLA		Not Available	SPADE CONNECTOR
015	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
NI	211737	248562		Terminal
"	NLA		Not Available	OVERLAY FOR CIRCUIT BOARD
018	212452			Board, Circuit
NI	NLA		Not Available	SEMS SCREW (No.4-40 X 1/2 INC)
020	212519	488234		Screw 8-32 X 1/4
021	212533			SHIELD FOR HEAT LAMP
NI	NLA		Not Available	SCREW, SHIELD TO CONTROL
"	NLA		Not Available	FRONT PLATE F/TICKET CONTRO
"	NLA		Not Available	BRACKET FOR TICKET ASSEMBLY
025	213074			Pin Receptacle For Plug
NI	NLA		Not Available	PIN FOR PLUG
"	NLA		Not Available	TICKET DEFLECTOR
"	NLA		Not Available	SCREW (No.6 X 1/4 INCH)
"	NLA		Not Available	SHIELD
030	214218			Lever, Switch
031	214220			Adjustment Thumb Wheel
032	214275			Roller For Cam
NI	NLA		Not Available	SCREW
"	NLA		Not Available	SPRING WASHER
035	Y311550		Not Available	SPADE (MINIATURE)
036	311612		Not Available	COVER, CIRCUIT BOARD TERMINALS
037	311613	Y311711		Screw, Fuse Block

the laundry company[®]

rows
the laundry company[®]