


Maytag GDE26CS 07 - LINT SCREEN\TUMBLER (FRONT & BACK)

MODEL DE-DG26CS

LINT SCREEN, TUMBLER, TUMBLER FRONT

& BACK



20

Maytag [Residential Maytag GDE26CS Dryer Parts](#) Parts Diagram 07 - LINT SCREEN\TUMBLER (FRONT & BACK)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	314803	33001012		Baffle
002	314804	33001004		Baffle, Tall
003	410233	9703438		Ring-Retrn
004	Y310376			Clip, Door Switch Harness
005	307108	33002970		Lint Filte
006	312538	33001443		Nut, Hex
007	Y307112	33001016		Outlet Duct Assembly
008	Y312959			Poly "V" Belt For Tumbler
009	210720			Rivet, Bearing To Tumbler Frmt
010	Y303373	12001541		Drum Roller/Washer Assembly--W
011	Y310759			Screw, Tumbler Baffles
012	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
013	Y314110	33002917		Screw, No.10-16
014	Y313561			Screw----NA
015	NLA		Not Available	SCREW

016	Y310632	1163839	Screw
017	314820		Seal, Tumbler
018	Y312948	6-3129480	Shaft- Tumbler
019	Y313347	312535	Washer, Vault Mounting Brk.
020	NLA	Not Available	COVER, THREAD
021	Y307114	33001178	Back, Tumbler
022	307109	33001179	Front, Tumbler
023	306508		Tumbler Bearing Kit ---W
024	314802	Not Available	TUMBLER W/OUT BAFFLES
025	306663	Not Available	TUMBLER W/BAFFLES
026	314158		Washer, Baffle To Tumbler
027	312535		Washer, Vault Mounting Brk.

the laundry company[®]

the laundry company[®]

the laundry company[®]